

# Instruction book

## Oil-injected screw compressors

GA 5 VSDs, GA 7 VSDs, GA 11 VSDs, GA 15 VSDs,  
GA 18 VSDs



# Atlas Copco

## Oil-injected screw compressors

GA 5 VSDs, GA 7 VSDs, GA 11 VSDs, GA 15 VSDs,  
GA 18 VSDs

### Instruction book

Original instructions

#### **COPYRIGHT NOTICE**

Any unauthorized use or copying of the contents or any part thereof is prohibited.

This applies in particular to trademarks, model denominations, part numbers and drawings.

This instruction book is valid for CE, non-CE as well as UKCA labelled machines. It meets the requirements for instructions specified by the applicable European directives or UK statutory instruments as identified in the Declaration of Conformity.

June 2023

No. 2920 7218 60

[www.atlascopco.com](http://www.atlascopco.com)



## Table of contents

<b>1</b>	<b>Safety precautions.....</b>	<b>6</b>
1.1	SAFETY ICONS.....	6
1.2	GENERAL SAFETY PRECAUTIONS.....	6
1.3	SAFETY PRECAUTIONS DURING INSTALLATION.....	8
1.4	SAFETY PRECAUTIONS DURING OPERATION.....	9
1.5	SAFETY PRECAUTIONS DURING MAINTENANCE OR REPAIR.....	10
1.6	DISMANTLING AND DISPOSAL.....	11
<b>2</b>	<b>General description.....</b>	<b>13</b>
2.1	INTRODUCTION.....	13
2.2	FLOW DIAGRAM.....	18
2.3	CONDENSATE SYSTEM.....	21
2.4	REGULATING SYSTEM.....	25
2.5	ELECTRICAL SYSTEM.....	26
2.6	AIR DRYER.....	27
<b>3</b>	<b>Controller.....</b>	<b>29</b>
3.1	CONTROLLER FUNCTIONS.....	29
3.2	CONTROL PANEL.....	31
3.3	ICONS USED.....	31
3.4	MAIN SCREEN.....	36
3.5	QUICK ACCESS SCREEN.....	37
3.6	MENU SCREEN.....	38
3.7	DATA MENU.....	39

3.8	SERVICE MENU.....	42
3.9	WEEK TIMER MENU.....	43
3.10	EVENT HISTORY MENU.....	44
3.11	MACHINE SETTINGS MENU.....	45
3.12	CONTROLLER SETTINGS MENU.....	47
3.13	ACCESS LEVEL.....	50
<b>4</b>	<b>Installation.....</b>	<b>52</b>
4.1	DIMENSION DRAWINGS.....	52
4.2	INSTALLATION PROPOSAL.....	54
4.3	ELECTRICAL CONNECTIONS.....	61
4.4	PICTOGRAPHS.....	63
4.5	INSTRUCTIONS FOR PROLONGED STORAGE.....	64
<b>5</b>	<b>Energy recovery.....</b>	<b>65</b>
5.1	ENERGY RECOVERY (ER) UNIT.....	65
5.2	ENERGY RECOVERY (ER) SYSTEMS.....	66
5.3	ENERGY RECOVERY (ER) OPERATION.....	67
5.4	ENERGY RECOVERY (ER) MAINTENANCE.....	69
5.5	ENERGY RECOVERY (ER) COOLING WATER REQUIREMENTS.....	69
5.6	ENERGY RECOVERY (ER) DATA.....	74
<b>6</b>	<b>Operating instructions.....</b>	<b>77</b>
6.1	INITIAL START-UP.....	77
6.2	STARTING.....	80
6.3	DURING OPERATION.....	80

6.4	STOPPING.....	82
6.5	TAKING OUT OF OPERATION.....	82
6.6	BOOSTFLOW.....	83
<b>7</b>	<b>Maintenance.....</b>	<b>85</b>
7.1	PREVENTIVE MAINTENANCE SCHEDULE.....	85
7.2	OIL SPECIFICATIONS.....	88
7.3	DRIVE MOTOR.....	89
7.4	AIR FILTER.....	89
7.5	OIL, OIL FILTER AND OIL SEPARATOR CHANGE.....	89
7.6	COOLERS.....	93
7.7	AIR DRYER.....	94
7.8	RH SENSOR.....	95
7.9	SAFETY VALVES.....	95
7.10	FILTERS.....	96
7.11	SERVICE KITS.....	96
7.12	DRAIN REPLACEMENT.....	97
<b>8</b>	<b>Problem solving.....</b>	<b>99</b>
<b>9</b>	<b>Technical data.....</b>	<b>114</b>
9.1	READINGS ON DISPLAY.....	114
9.2	ELECTRIC CABLE SIZE AND FUSES.....	114
9.3	REFERENCE CONDITIONS AND LIMITATIONS.....	122
9.4	COMPRESSOR DATA.....	123
9.5	TECHNICAL DATA CONTROLLER.....	128
9.6	INPUTS AND OUTPUTS.....	129

<b>10</b>	<b>Instructions for use.....</b>	<b>133</b>
<b>11</b>	<b>Guidelines for inspection.....</b>	<b>134</b>
<b>12</b>	<b>Pressure equipment directives.....</b>	<b>135</b>
<b>13</b>	<b>Declaration of conformity.....</b>	<b>137</b>

# 1 Safety precautions

## 1.1 Safety icons



**Danger:** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



**Warning:** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



**Notice:** Indicates a potential situation which, if not avoided, might result in property damage or in an undesirable result or state.



**Note:** Indicates important information.

## 1.2 General safety precautions

- The operator must employ safe working practices and observe all related work safety requirements and regulations.
- If any of the following statements does not comply with the applicable legislation, the stricter of the two shall apply.
- Installation, operation, maintenance and repair work must only be performed by authorized, trained, specialized personnel. The personnel should apply safe working practices by use of personal protection equipment, appropriate tools and defined procedures.
- The compressor is not considered capable of producing air of breathing quality. For air of breathing quality, the compressed air must be adequately purified according to the applicable legislation and standards.
- Before any maintenance, repair work, adjustment or any other non-routine checks, switch the controller in service mode (see section *Service mode*), stop the compressor, press the emergency stop button, switch off the voltage and depressurize the compressor. In addition, the power isolating switch must be opened and locked. The process of locking, tagging and trying to turn on the equipment to confirm it cannot operate is called Lock Out, Tag Out (LOTO).

On units powered by a frequency converter, wait 10 minutes after switching off the voltage, before starting any electrical repair.



**Warning:** In a domestic environment, this product may cause radio interference, in which case supplementary mitigation measures are required.



**Danger:** If the machine is equipped with an automatic restart after voltage failure function and if this function is active, be aware that the machine will restart automatically when the power is restored if it was running when the power was interrupted!

- Never play with compressed air. Do not apply the air to your skin or direct an air stream at people. Never use the air to clean dirt from your clothes. When using the air to clean equipment, do so with extreme caution and wear eye protection.
- The owner is responsible for maintaining the unit in safe operating condition. Parts and accessories shall be replaced if unsuitable for safe operation.
- It is not allowed to walk or stand on the unit or on its components.



- If compressed air is used in the food industry and more specifically for direct food contact, it is recommended, for optimal safety, to use certified Class 0 compressors in combination with appropriate filtration depending on the application. Please contact your customer center for advice on specific filtration.
- The service switch should only be operated by a trained service specialist from the manufacturer.

## Residual risks

Based on the output of the Failure Mode and Effects Analysis (FMEA) and Safety Review the following residual risks have been identified.

Residual risks are risks that remain at a certain level even after careful risk identification/assessment and risk mitigation/elimination.



**Danger: Risk of fire**

Timely service the filters, oil separator element and oil.



**Danger: Risk of fire**

Use the recommended branded oil and grease.



**Danger: Risk of fire**

Timely inspect the unit.



**Danger: Risk of electrocution**

Follow the labels and maintenance instructions.



**Danger: Risk of electrocution or fire**

Timely check the electrical insulation for damage.



**Danger: Risk of fire**

Make sure the cable sizing is correct.



**Danger: Risk of fire**

Timely check that the circuit breakers are working correctly. Make sure that the correct circuit breakers are used.



**Danger: Risk of fire**

Timely check that the temperature switch is working correctly.



**Danger: Risk of fire**

Make sure that the transformer setting is correct.



**Danger: Risk of electrocution or mechanical shock**

Make sure that the procedures to relief pneumatic and/or electric energy (e.g. Lock Out, Tag Out (LOTO), wait time, pressure relief actions) are followed correctly.



**Danger: Risk of fire or explosion**

Make sure that the unit is not operated outside of the ambient condition limits (e.g. intake of flammable gases).

### 1.3 Safety precautions during installation



**Warning:** All responsibility for any damage or injury resulting from neglecting these precautions, or non-observance of the normal caution and care required for installation, operation, maintenance and repair, even if not expressly stated, will be disclaimed by the manufacturer.

- The machine must only be lifted using suitable equipment in accordance with the applicable safety regulations. Loose or pivoting parts must be securely fastened before lifting. It is strictly forbidden to dwell or stay in the risk zone under a lifted load. Lifting acceleration and deceleration must be kept within safe limits. Wear a safety helmet when working in the area of overhead or lifting equipment.
- The unit is designed for indoor use. If the unit is installed outdoors, special precautions must be taken. Consult your supplier.
- Place the machine where the ambient air is as cool and clean as possible. If necessary, install a suction duct. Never obstruct the air inlet. Care must be taken to minimize the entry of moisture at the inlet air.
- Any blanking flanges, plugs, caps and desiccant bags must be removed before connecting the pipes.
- Air hoses must be of correct size and suitable for the working pressure. Never use frayed, damaged or worn hoses. Distribution pipes and connections must be of the correct size and suitable for the working pressure.
- The aspirated air must be free of flammable fumes, vapors and particles, e.g. paint solvents, that can lead to internal fire or explosion.
- Arrange the air intake so that loose clothing worn by people cannot be drawn in.
- Ensure that the discharge pipe from the compressor to the after-cooler or air net is free to expand under heat and that it is not in contact with or close to flammable materials.
- No external force may be exerted on the air outlet valve; the connected pipe must be free of strain.
- If remote control is installed, the machine must bear a clear sign stating: **DANGER: This machine is remotely controlled and may start without warning.**

The operator has to make sure that the machine is stopped and depressurized and that the electrical isolating switch is open, locked and labelled with a temporary warning before any maintenance or repair. As a further safeguard, persons switching on or off remotely controlled machines shall take adequate precautions to ensure that there is no one checking or working on the machine. To this end, a suitable notice shall be affixed to the start equipment.

- Air-cooled machines must be installed in such a way that an adequate flow of cooling air is available and that the exhausted air does not recirculate to the compressor air inlet or cooling air inlet.
- The electrical connections must correspond to the applicable codes. The machines must be earthed and protected against short circuits by fuses in all phases. A lockable power isolating switch must be installed near the compressor.
- On machines with automatic start/stop system or if the automatic restart function after voltage failure is activated, a sign stating "This machine may start without warning" must be affixed near the instrument panel.
- In multiple compressor systems, manual valves must be installed to isolate each compressor. Non-return valves (check valves) must not be relied upon for isolating pressure systems.

- Never remove or tamper with the safety devices, guards or insulation fitted on the machine. Every pressure vessel or auxiliary installed outside the machine to contain air above atmospheric pressure must be protected by a pressure relieving device or devices as required.
- Piping or other parts with a temperature in excess of 70°C (158°F) and which may be accidentally touched by personnel in normal operation must be guarded or insulated. Other high temperature piping must be clearly marked.
- If the ground is not level or can be subject to variable inclination, consult the manufacturer.
- In an installation with multiple compressors, the outlet piping must be installed in such a way that condensate cannot flow back into the compressor. See section *Installation proposal*.



**Note:** Also consult the following safety precautions: *Safety precautions during operation* and *Safety precautions during maintenance or repair*.

These precautions apply to machinery processing or consuming air or inert gas. Processing of any other gas requires additional safety precautions typical to the application which are not included herein.

Some precautions are general and cover several machine types and equipment; hence some statements may not apply to your machine.

## 1.4 Safety precautions during operation



**Warning:** All responsibility for any damage or injury resulting from neglecting these precautions, or non-observance of the normal caution and care required for installation, operation, maintenance and repair, even if not expressly stated, will be disclaimed by the manufacturer.

- Never touch any piping or components of the machine during operation.
- Use only the correct type and size of hose end fittings and connections. When blowing through a hose or air line, ensure that the open end is held securely. A free end will whip and may cause injury. Make sure that a hose is fully depressurized before disconnecting it.
- Persons switching on remotely controlled machines shall take adequate precautions to ensure that there is no one checking or working on the machine. To this end, a suitable notice shall be affixed to the remote start equipment.
- Never operate the machine when there is a possibility of taking in flammable or toxic fumes, vapors or particles.
- Never operate the machine below or in excess of its limit ratings.
- Keep all bodywork doors shut during operation. The doors may be opened for short periods only, e.g. to carry out routine checks. Wear ear and eye protection when opening a door.

On machines without bodywork, wear ear protection in the vicinity of the machine.

- People staying in environments or rooms where the sound pressure level reaches or exceeds 80 dB(A) shall wear ear protectors.
- Periodically check that:
  - All guards are in place and securely fastened
  - All hoses and/or pipes inside the machine are in good condition, secure and not rubbing
  - No leaks occur
  - All fasteners are tight
  - All electrical leads are secure and in good order
  - Safety valves and other pressure relief devices are not obstructed by dirt or paint

- Air outlet valve and air net, i.e. pipes, couplings, manifolds, valves, hoses, etc. are in good repair, free of wear or abuse
- All pre-filters are not clogged
- If warm cooling air from compressors is used in air heating systems, e.g. to warm up a workroom, take precautions against air pollution and possible contamination of the breathing air.
- Do not remove any of, or tamper with, the sound-damping material.
- Never remove or tamper with the safety devices, guards or insulations fitted on the machine. Every pressure vessel or auxiliary installed outside the machine to contain air above atmospheric pressure shall be protected by a pressure relieving device or devices as required.
- Yearly inspect the air receiver. Minimum wall thickness as specified in the instruction book must be respected. Local regulations remain applicable if they are more strict.



**Note:** Also consult the following safety precautions: *Safety precautions during operation* and *Safety precautions during maintenance or repair*.

These precautions apply to machinery processing or consuming air or inert gas. Processing of any other gas requires additional safety precautions typical to the application which are not included herein.

Some precautions are general and cover several machine types and equipment; hence some statements may not apply to your machine.

## 1.5 Safety precautions during maintenance or repair



**Warning:** All responsibility for any damage or injury resulting from neglecting these precautions, or non-observance of the normal caution and care required for installation, operation, maintenance and repair, even if not expressly stated, will be disclaimed by the manufacturer.

- Always use the correct safety equipment (such as safety glasses, gloves, safety shoes, etc.).
- Use only the correct tools for maintenance and repair work.
- Use only genuine spare parts for maintenance or repair. The manufacturer will disclaim all damage or injuries caused by the use of non-genuine spare parts.
- All maintenance work shall only be undertaken when the machine has cooled down.
- A warning sign bearing a legend such as "Work in progress; do not start" shall be attached to the starting equipment.
- Persons switching on remotely controlled machines shall take adequate precautions to ensure that there is no one checking or working on the machine. To this end, a suitable notice shall be affixed to the remote start equipment.
- Close the compressor air outlet valve and depressurize the compressor before connecting or disconnecting a pipe.
- Before removing any pressurized component, effectively isolate the machine from all sources of pressure and relieve the entire system of pressure. See section *Maintenance*.
- Never use flammable solvents or carbon tetrachloride for cleaning parts. Take safety precautions against toxic vapors of cleaning liquids.
- Scrupulously observe cleanliness during maintenance and repair. Keep dirt away by covering the parts and exposed openings with a clean cloth, paper or tape.
- Never weld or perform any operation involving heat near the oil system. Oil tanks must be completely purged, e.g. by steam cleaning, before carrying out such operations. Never weld on, or in any way modify, pressure vessels.

- Whenever there is an indication or any suspicion that an internal part of a machine is overheated, the machine shall be stopped but no inspection covers shall be opened before sufficient cooling time has elapsed; this to avoid the risk of spontaneous ignition of the oil vapor when air is admitted.
- Never use a light source with open flame for inspecting the interior of a machine, pressure vessel, etc.
- Make sure that no tools, loose parts or rags are left in or on the machine.
- When replacing the air filter, make sure no dirt, dust, rags, tools or loose parts can fall in the air inlet.
- All regulating and safety devices shall be maintained with due care to ensure that they function properly. They may not be put out of action.
- Before clearing the machine for use after maintenance or overhaul, check that operating pressures, temperatures and time settings are correct. Check that all control and shut-down devices are fitted and that they function correctly. If removed, check that the coupling guard of the compressor drive shaft has been reinstalled.
- Every time the separator element is renewed, examine the discharge pipe and the inside of the oil separator vessel for carbon deposits; if excessive, the deposits should be removed.
- Protect the motor, air filter, electrical and regulating components, etc. to prevent moisture from entering them, e.g. when steam cleaning.
- Make sure that all sound-damping material and vibration dampers, e.g. damping material on the bodywork and in the air inlet and outlet systems of the compressor, is in good condition. If damaged, replace it by genuine material from the manufacturer to prevent the sound pressure level from increasing.
- Never use caustic solvents which can damage materials of the air net, e.g. polycarbonate bowls.
- **Only if applicable, the following safety precautions are stressed when handling refrigerant:**
  - Never inhale refrigerant vapors. Check that the working area is adequately ventilated; if required, use breathing protection.
  - Always wear special gloves. In case of refrigerant contact with the skin, rinse the skin with water. If liquid refrigerant contacts the skin through clothing, never tear off or remove the latter; flush abundantly with fresh water over the clothing until all refrigerant is flushed away; then seek medical first aid.
- Protect hands to avoid injury from hot machine parts, e.g. during draining of oil.
- Be aware of eventual sharp edges on certain parts of the machine.



**Note:** Also consult the following safety precautions: *Safety precautions during operation* and *Safety precautions during maintenance or repair*.

These precautions apply to machinery processing or consuming air or inert gas. Processing of any other gas requires additional safety precautions typical to the application which are not included herein.

Some precautions are general and cover several machine types and equipment; hence some statements may not apply to your machine.

## 1.6 Dismantling and disposal

The device must be disposed according to local regulations. The product is not designed for refurbishing after finished lifecycle.

## Dismantling

Once the end of life of the machine is reached, please follow next steps:

1. Stop the machine.
2. Check all safety precautions mentioned in the previous chapters to secure safe handling (e.g. LOTO, cool-down, depressurize, discharge, etc.).
3. Have trained personnel dismantle the installation.
4. Separate the harmful from the safe components (e.g. drain oil from parts containing oil).
5. Refer to the disposal topic below.

## Disposal of electrical and electronic appliances (WEEE)

This equipment falls under the provisions of the European Directive 2012/19/EU on waste electrical and electronic appliances (WEEE) as well as under the UKCA Waste Electrical and Electronic Equipment regulations 2013 and may not be disposed as unsorted waste.



The equipment is labelled in accordance with the European Directive 2012/19/EU and the UKCA Waste Electrical and Electronic Equipment regulations 2013 with the crossed-out wheeled bin symbol.

At the end of life-time of the electric and electronic equipment (EEE) it must be taken to separate collection.

For more information check with your local waste authority, customer center or distributor.

## Disposal of other used material

Used filters or any other used material (e.g. filter bags, filter media, desiccant, lubricants, cleaning rags, machine parts, etc.) must be disposed of in an environmentally friendly and safe manner, and in line with the local recommendations and environmental legislation.

## 2 General description

### 2.1 Introduction

GA 5 VSD<sup>s</sup> up to GA 18 VSD<sup>s</sup> are single-stage, oil-injected screw compressors driven by a reluctance motor.

The compressors are controlled by the Elektronikon™ Touch controller (ER).

The compressors use VSD (English: Variable Speed Drive) technology. This means that motor and fan speed are automatically adjusted, depending on compressed air demand.

The compressors are air-cooled and are enclosed in a sound-insulated bodywork.

There are 2 versions of the compressor: Pack (without integrated dryer) and Full-Feature (with integrated dryer).

GA 5 VSD<sup>s</sup> up to GA 11 VSD<sup>s</sup> will also be available with an integrated air tank.

When considering performance and condensate prevention, the VSD<sup>s</sup> compressor has 2 important features:

- **Smart Temperature Control (STC) valve:** The STC valve is a thermostatic valve which is electronically regulated. The setpoint of the STC valve is calculated in the controller and sent to the STC valve through a CAN bus. This enables the compressor to regulate the machine to the most optimal temperature, best suited to its specific conditions. In contrast to a classic thermostat, where the temperature setpoint is always fixed at a certain value.
- **VSD fan:** In contrast to most air-cooled compressors, the main cooling fan of the VSD<sup>s</sup> compressors is a VSD fan instead of a fixed speed fan. This means that the speed of the cooling fan may have any value between the minimum and maximum speed of the fan. This results in a more stable temperature regulation with less undershoots and overshoots compared to a fixed speed fan.

The STC valve and VSD fan will cooperate to make the compressor run at the most optimal temperature in all conditions while at the same time preventing the formation of condensate.

Relative humidity will determine the setpoint for the STC valve and the VSD fan.

Pack




Figure 1: Front view, Pack





Figure 2: Open side view, Pack



## Full-Feature

The Full-Feature compressors have an air dryer which is integrated in the sound-insulated bodywork. The dryer removes condensate from the compressed air by cooling the air to near freezing point.



**Figure 3: Front view, GA5-11 VSD<sup>s</sup>, Full-Feature**




Figure 4: Front view, GA15-18 VSDs, Full-Feature




Figure 5: Open side view, Full-Feature

Reference	Description
AF	Air filter
AR	Air receiver
AV	Air outlet
Ca	Air cooler
Co	Oil cooler
D	Compressor drive / converter
Da	Automatic condensate outlet
Dm	Manual condensate outlet
DR	Refrigerant dryer
E	Compressor element
ED	Electronic water drain
ER	Elektronikon™ Touch controller
FN	Cooling fan
M	Drive motor
MPV	Minimum pressure valve
OF	Oil filter
OS	Oil separator element
S3	Emergency stop button
STC	Smart temperature control valve
RH	Relative humidity sensor
Vp	Minimum pressure valve

## 2.2 Flow diagram




Figure 6: GA 5-18 VSD<sup>s</sup>, Pack




Figure 7: GA 5-11 VSD<sup>s</sup>, Pack, Tank-mounted




Figure 8: GA 5-18 VSD<sup>s</sup>, Full-Feature




Figure 9: GA 5-11 VSD<sup>s</sup>, Full-Feature, Tank-mounted

Reference	Description
A	Air inlet
B	Air/oil mixture
C	Oil
D	Wet compressed air
E	Condensate
F	Dry compressed air (Full-Feature)

### Air flow

Air comes in through filter (AF) and inlet valve (IV) and is compressed in the compressor element (E).

A mixture of compressed air and oil flows into the air receiver/oil separator (AR) where oil and air are separated.

The air flows through the minimum pressure valve (Vp), the air cooler (Ca), and the condensate trap (MT) to the outlet valve (AV).

Minimum pressure valve (Vp) prevents the receiver pressure from dropping below a minimum pressure and includes a check valve which prevents back-flow of compressed air from the net.

The air then flows through the air cooler (Ca) where condensate is removed by the drain.

For tank-mounted units, the air flows from the cooler to the air tank.

Full-Feature compressors have a dryer (DR) after the air cooler, which removes additional condensate from the compressed air.

For Full-Feature, tank-mounted units, the air flows from the dryer to the air tank.

### Oil circuit

The air receiver (AR) removes most of the oil from the air/oil mixture by centrifugal action. The oil collects in the lower part of the air receiver (AR) which serves as oil tank.

The oil separator (OS) removes the remaining oil.

The remaining oil is injected into the motor. A check valve (CV) in the scavenge line circuit prevents back-flow.

The oil circuit has an electrically regulated Smart Temperature Control (STC) valve that prevents the oil from flowing through the oil cooler (Co) when the oil temperature is low.

Air pressure forces the oil from air receiver (AR) through the cooler if required, and then through the oil filter (OF).

The filtered oil flows through the cooling channels of the reluctance motor to the compressor element (E).

### Cooling on air-cooled compressors


The cooling system has an air cooler (Ca) and an oil cooler (Co).

The fan (FN) pulls air over the coolers. This fan is regulated in speed by the VSD drive, depending on the operating conditions, according to a specific algorithm.


## 2.3 Condensate system

### Drain connections


The compressors have an electronic condensate drain (ED).




**Figure 10: Location of the electronic condensate drain, Pack**



**Figure 11: Location of the electronic condensate drain, Pack, Tank-mounted**



**Figure 12: Location of the electronic condensate drain, Full-Feature**



**Figure 13: Location of the electronic condensate drain, Full-Feature, Tank-mounted**

On Pack units, the condensate formed in the air cooler (Ca) is collected in the condensate trap (MT) and discharged by the electronic drain (ED).

On Pack, tank-mounted units, a second electronic drain removes the condensate formed in the air tank that is collected in the lower part of the air tank.

On Full-Feature units, a second electronic drain removes the condensate formed in the dryer that is collected in the lower part of the heat exchanger/evaporator

On Full-Feature, tank-mounted units, a third electronic drain removes the condensate formed in the air tank that is collected in the lower part of the air tank.

When the condensate in the electronic drain reaches a certain level, it is drained via the automatic drain outlet (Da).






**Figure 14: Condensate drain connections, Pack**



**Figure 15: Condensate drain connections, Full-Feature**

Reference	Description
Da	Automatic drain connection
Dm	Manual drain connection



**Figure 16: Electronic condensate drain (ED)**

The Test button (2) on top of the drain can be used in three different ways, according the situation:

- When pressed during normal operation, it starts the manual drain test.

- When pressed during an alarm, it resets the control logic.
- By pressing the Test button for at least 5 seconds, the self diagnosis routine will start.

**LED explanation**

Operation		Description	RGB LED	Purge valve
0	Power on	The drain CPU starts up and loads internal data. LEDs show the firmware version installed.	<ol style="list-style-type: none"> <li>1. Green LED blinks 3 times.</li> <li>2. Red LED blinks 2 times.</li> <li>3. Yellow LED stays on.</li> </ol>	
1	Standby	The drain is ready to operate and is activated through floater movement. Every 30 minutes a routine is started to keep drain clean from oil/condensate residues.	Green LED stays on: connected mode.	<ol style="list-style-type: none"> <li>1. 2 seconds on.</li> <li>2. 30 seconds off.</li> </ol>
			Yellow LED stays on: standalone mode.	
2	Automatic discharge	The drain discharges condensate when activated by the floater moving to the top of the housing. The valve opens after a 5 seconds delay in order to collect extra condensate. When the floater returns back to its original position, the valve closes.	Green LED stays on: connected mode.	On until the condensate chamber is almost empty (until the hall sensor signal drops out).
			Yellow LED stays on: standalone mode.	
3	Cleaning routine	If the floater is stuck at the top of the housing for 10 seconds, the drain starts a cleaning operation. When the floater moves down, that routine stops immediately and the drain goes into standby.	Green LED blinking: connected mode.	<ol style="list-style-type: none"> <li>1. 2 seconds on, 2 seconds off (repeat 30 times).</li> <li>2. 1 minute pause.</li> <li>3. Repeat.</li> </ol>
			Yellow LED blinking: standalone mode.	

Operation		Description	RGB LED	Purge valve
4	Timer routine	If the floater is still stuck after the cleaning routine, the drain switches to the timer routine. When the floater moves down, that routine stops immediately and the drain goes into standby.	Green LED blinking: connected mode.	<ol style="list-style-type: none"> <li>1. 1 second on.</li> <li>2. 1 minute off.</li> </ol>
			Yellow LED blinking: standalone mode.	
5	Manual discharge	Push test button to discharge manually. The drain discharges condensate even if the test button remains pressed (for 3 seconds maximum).	Green LED blinking: connected mode.	On until the button is pushed (maximum 3 seconds).
			Yellow LED blinking: standalone mode.	
6	Reset	Push test button for 5 seconds to reset the drain.	<ol style="list-style-type: none"> <li>1. Both LEDs switch off for 1 second.</li> <li>2. Green LED blinks 3 times.</li> <li>3. Red LED blinks 2 times.</li> </ol>	
7	Failure	Drain hardware failure.	Red LED stays on.	

(1) Connected mode means there is communication with the Elektronikon™ controller.

(2) Standalone mode means there is no communication with the Elektronikon™ controller. The drain can also work without communication, but you will get no notifications of failure, temperature, cycles, etc. to the Elektronikon™ controller and SMARTLINK.

## 2.4 Regulating system

### Description

When the compressor is started and the net pressure is below the setpoint, the motor speed increases until the net pressure reaches the setpoint or until the maximum motor speed is reached.

If the air consumption is less than the air delivery of the compressor, the net pressure increases further.


When the net pressure reaches the setpoint (desired net pressure) and continues to rise, the regulator decreases the motor speed.

When the pressure continues to increase although the motor already operates at minimum speed, the regulator stops the motor as soon the net pressure reaches a value, equal to the setpoint plus the indirect stop level (typically 0.3 bar above the setpoint).

Should the net pressure rise very quickly to a value equal to the setpoint plus the direct stop level (typically 1 bar above the setpoint), the compressor is stopped immediately (without first decreasing the motor speed).

No compressed air is lost when the compressor is stopped in automatic operation, thus saving valuable energy.

If the compressor was stopped in automatic operation and the net pressure approaches the setpoint, the regulator starts the motor again. The quicker the net pressure drops, the quicker the compressor will restart.

 **Note:** The pressure in the oil separator vessel is only released to the atmosphere when the compressor is stopped manually or in case of an emergency stop. See section *Stopping*.

## 2.5 Electrical system

### Electrical components

The electrical system comprises the following components:



Figure 17: Electrical components

Reference	Description
N	Neos Next


### Electrical diagrams

The complete electrical diagram can be found in the technical documentation, supplied with the unit.

## 2.6 Air dryer

Full-Feature units are equipped with an air dryer.

### Flow diagram



86406

**Figure 18: Flow diagram, air dryer**

Reference	Description
AI	Air inlet
AO	Air outlet
1	Air/air heat exchanger
2	Air/refrigerant heat exchanger/evaporator
3	Condensate separator
4	Automatic drain/condensate outlet
5	Refrigerant compressor
6	Refrigerant condenser
7	Liquid refrigerant dryer/filter
8	Thermostatic bypass valve
9	Hot gas bypass valve
10	Condenser cooling fan
11	Liquid separator

### Compressed air circuit

Compressed air enters heat exchanger (1) and is cooled by the outgoing, cold, dried air. Water in the incoming air starts to condense. The air then flows through heat exchanger/evaporator (2), where the refrigerant evaporates, causing the air to be cooled further to close to the evaporating temperature of the refrigerant. More water in the air condenses. The cold air then flows through separator (3) where all the condensate is separated from the air. The condensate is automatically drained through condensate drain (4).

The cold, dried air flows through heat exchanger (1) where it is warmed up by the incoming air.

## Refrigerant circuit

Compressor (5) delivers hot, high-pressure refrigerant gas which flows through condenser (6) where most of the refrigerant condenses.

The liquid refrigerant flows through liquid refrigerant dryer/filter (7) to thermostatic expansion valve (8). The refrigerant leaves the capillary tube at about evaporating pressure.

The refrigerant enters evaporator (2) where it withdraws heat from the compressed air by further evaporation at about constant pressure. The heated refrigerant leaves the evaporator and is sucked in by the compressor (5) through a liquid separator (12).

Bypass valve (9) regulates the refrigerant flow. Fan (10) is regulated depending on the pressure degree of the condensate.

## 3 Controller

### 3.1 Controller functions



Figure 19: Elektronikon™ Touch controller

#### Introduction

The controller has the following functions:

- Controlling the unit.
- Protecting the unit.
- Monitoring components subject to service.
- Automatic restart after voltage failure (ARAVF).

This function can only be activated by a service technician.

#### Automatic control of the unit

The controller maintains the net pressure between programmable limits by automatically loading and unloading the unit (fixed speed units) or by adapting the motor speed (units with frequency converter).

A number of programmable settings, e.g. the unloading and loading pressures (for fixed speed units), the setpoint (for units with frequency converter), the minimum stop time, the maximum number of motor starts and several other parameters are taken into account.

The controller stops the unit whenever possible to reduce the power consumption and restarts it automatically when the net pressure decreases. If the expected unloading period is too short, the unit is kept running to prevent too short standstill periods.



**Warning:** A number of time-based automatic start/stop commands may be programmed. Take into account that a start command will be executed (if programmed and activated), even after manually stopping the unit.

## Shutdown

Several sensors are provided on the unit. If one of the measured signals exceeds the programmed shutdown level, the unit will be stopped.

Example: If the outlet pressure exceeds the programmed shutdown level, the unit will be stopped. This will be indicated on the display of the controller.

The unit will also be stopped in case of overload of the drive motor or fan motor.



### **Warning:**

Before remedying, consult the safety precautions.

Before resetting a warning or shutdown message, an authorized technician should solve the problem. If a warning or alarm persists to occur, consult your supplier. Frequently resetting these messages without remedying may damage the unit.

## Shutdown warning

A shutdown warning level is a programmable level below the shutdown level.

If one of the measurements exceeds the programmed shutdown warning level, a message will appear on the display and the general alarm LED will light up to warn the operator before the shutdown level is reached.

The message disappears as soon as the warning condition disappears.

When the shutdown warning is shown, press the stop button to stop the unit and wait until the unit has stopped. Consult an authorized technician to solve the problem.

A warning will also appear if the dew point temperature is too high (on units with integrated dryer).

## Service warning

A number of service operations are grouped as a Service Plan. Each Service Plan has a programmed time interval. If the service timer exceeds a programmed value, this will be indicated on the display to warn the operator to carry out the service actions belonging to that Service Plan.

When the service warning is shown, stop the unit, switch off the voltage and carry out the required service actions.



**Warning:** Ignoring this service warning could severely damage your machine in the long term. The supplier is not liable for failures caused by neglecting service interval timings.

## Automatic restart after voltage failure (ARAVF)

The controller has a built-in function to automatically restart the unit when the voltage is restored after voltage failure.

For units leaving the factory, this function is made inactive. If desired, the function can be activated. Consult your supplier.



### **Warning:**

If the function is activated and the controller was in the automatic operation mode before the supply voltage was interrupted, the unit will automatically restart once the supply voltage to the unit is restored. The ARAVF label shall be attached near to the controller.



### 3.2 Control panel



























Figure 20: Control panel














Reference	Designation	Function
1	Touch screen	Shows the unit operating condition and several icons to navigate through the menu. The screen can be operated by touch.
2	Warning sign	Flashes in case of a shut-down, is lit in case of a warning condition.
3	Service sign	Lit when service is needed.
4	Operation sign	Lit when the unit is running in automatic operation.
5	Voltage sign	Indicates that the voltage is switched on.
6	Stop button	Stops the unit.
7	Start button	This button starts the unit. The operation sign lights up. The controller is operative.

### 3.3 Icons used








#### Menu icons








Menu	Icon	Menu	Icon	Menu	Icon
Data	85233D	Status	85239D		

Menu	Icon	Menu	Icon	Menu	Icon
		Inputs	 85240D		
		Outputs	 85241D		
		Counters	 85242D		
		Auxiliary Equipment Parameters	 85243D	Converters	 85251D
Service	 85234D	Service		Overview	 85252D
				Service Plan	 85253D
				Service History	 85254D
		Service Functions	 85244D		
		Clean Screen	 85302D		
Week Timer	 85235D			Week	 85303D
				Remaining Running Time	 85304D
Event History	 85236D	Saved Data	 85245D		
Machine Settings	 85237D	Alarms	 85239D		
		Regulation	 85346D		
		Control Parameters	 85347D		
		Auxiliary Equipment Parameters	 85243D	Converters	 85251D
				Fan	 85255D
				Internal SmartBox	 85256D











Menu	Icon	Menu	Icon	Menu	Icon
				STC valve	 86405
		Auto Restart	 85274D		
Controller Settings	 85238D	Network Settings	 85246D	Ethernet Settings	 ENET 85257D
				CAN Settings	 CAN 85258D
		Localisation	 85247D	Language	 85259D
				Date/Time	 85260D
				Units	 bar   psi °C   °F l/s   m³/h 85261D
		User Password	 **** 85248D		
		Help	 85249D		
		Information	 85250D		











**Status icons**

Icon	Description
 85262D	Motor Stopped
 85263D	Motor Stopped Wait
 85264D	Running Unloaded
 85265D	Manual Unload
 85266D	Running Unloaded Wait
 85267D	Running Loaded
 85268D	Failed to Load






Icon	Description
 85269D	Running Loaded Wait
 85270D	Manual Stop
 85271D	Machine Control Mode, Local
 85272D	Machine Control Mode, Remote
 85273D	Machine Control Mode, LAN
 85274D	Automatic Restart After Voltage Failure
 85275D	Week Timer Active

**System icons**

Icon	Description
 85276D	Basic User
 85277D	Advanced User
 85278D	Service User
 85279D	Antenna 25%
 85280D	Antenna 50%
 85281D	Antenna 75%
 85282D	Antenna 100%
 85283D	Change between screens (indication)
 85284D	Energy recovery
 85285D	Dryer

Icon	Description
 85286D	Element
 85287D	Drain(s)
 4-20mA 85288D	Analogue Output
 85289D	Menu
 85290D	Reset
 85291D	Auto Restart
 85292D	Filter(s)
 85293D	Cooler
 85294D	Valve(s)
 85295D	Power Meter

### Input icons

Icon	Description
 85296D	Pressure
 85297D	Temperature
 85298D	Special Protection
 85299D	Open
 85300D	Closed



**Note:**


This chapter gives a general survey of available icons. Not all icons mentioned in this chapter are applicable to every machine.

### 3.4 Main screen

#### Function

The main screen is the screen that is shown automatically when the voltage is switched on. It is switched off automatically after a few minutes when there is no touch input.

#### Description



Reference	Designation	Function
1	Home button	The home button is always shown and can be tapped to return to the main screen.
2	Screen information	On the main screen, the screen information bar shows the serial number of the machine. When scrolling through menus, the name of the current menu is shown.
3	Access level button	The access level button is always shown and can be tapped to change the current user access level.
4	Alarm button	The alarm button can be tapped to show the current alarms. If an alarm occurs, the icon on the button will be red.
5	Service button	The service button can be tapped to show the service information.
6	Status	This icon shows the current status of the unit.
7	Page indicator	Indicates which page you currently see. The middle indication is the main screen, left is the menu screen and at the right the quick access screen. Swipe left or right to go to another screen.
8, 9, 10, 11	These fields can contain a certain value, depending on the type of the unit.	Tap the field to view the type of measurement. This will be shown in the screen information bar. Examples of values shown: <ul style="list-style-type: none"> <li>• Temperature</li> <li>• Pressure</li> <li>• Purity level</li> </ul>
12	Menu button	The menu button is always shown and can be tapped to go to the menu.

### 3.5 Quick access screen


**Function**

The screen is used to directly access some frequently used functions.

**Procedure**

The quick access screen can be viewed by swiping left, starting from the main screen.

**Description**



Through this screen, several important settings can be viewed and modified.

Reference	Function	Description
1	Setpoints	Several setpoints can be modified by tapping this icon.
2	Control mode	The control mode can be changed by tapping this icon. <ul style="list-style-type: none"> <li>Local control via start/stop buttons</li> <li>Remote control via digital input(s)</li> <li>LAN control via the network.</li> </ul> When in remote or LAN control, the start/stop buttons on the controller will not work.
3	Display language	The display language of the controller can be changed by tapping this icon.
4	Operation mode	When tapped, the operation mode can be chosen between manual and automatic. When manual mode is selected, the controller will switch to automatic mode automatically after 24 hours.
5	Week timer	Week timers can be set by tapping this icon.
6	Remaining running time	The remaining running time can be set and modified by tapping this icon.
7	Internal SmartBox	The reception quality of the internal antenna can be monitored. Each bar represents 25% reception strength. If the four bars are filled, the reception strength is 100%. If only one bar is filled, the reception strength is just 25%.

Reference	Function	Description
8	Auto Restart	Auto restart can be activated by tapping this icon.

## 3.6 Menu screen


### Function

This screen is used to display the different menus where settings can be viewed or changed.

### Procedure

The menu screen can be viewed by tapping the menu button or by swiping right, starting from the main screen.

### Description




85204

Reference	Designation	Function
(1)	Data	The data menu contains the status of the unit, information about the inputs, outputs and counters. The auxiliary equipment can also be viewed through this menu.
(2)	Service	The service menu contains the service information. The "clean screen" function can be used to clean the touchscreen.
(3)	Week timer	Multiple week timers and a remaining running time can be set through this menu.
(4)	Event history	In case of an alarm, the status information of the unit is saved and can be viewed through this menu.
(5)	Machine settings	Alarms settings, regulation settings and control parameters can be changed through this menu. Auxiliary equipment parameters can also be changed. The automatic restart function can be set through this menu. This function is password-protected.
(6)	Controller settings	Network settings, localisation settings and a user password can be set through this menu. There is also a help page available and the controller information can be shown.



## Menu structure

Operating the controller can be done by swiping through screens and tapping icons or menu items.



This is the main structure. It can differ depending on the configuration of the unit.

## 3.7 Data menu

### Function

This screen is used to display the following submenus:

- **Status**
- **Inputs**
- **Outputs**
- **Counters**
- **Auxiliary Equipment**


These submenus can be entered by tapping the icons.

### Procedure

To enter the **Data** menu screen:

1. Tap the **Menu** button.
2. Tap the **Data** icon.


## Description



Reference	Description
(1)	<b>Status</b> menu
(2)	<b>Inputs</b> menu
(3)	<b>Outputs</b> menu
(4)	<b>Counters</b>
(5)	<b>Auxiliary equipment</b> menu

### Status menu

Tap the **Status** icon to enter the **Status** menu.



This menu shows the current status of the unit.

If an alarm is active, it can be viewed by tapping the alarm message. To reset an alarm, tap the reset button.




**Warning:**

Before remedying, consult the safety precautions.

Before resetting a warning or shutdown message, an authorized technician should solve the problem. If a warning or alarm persists to occur, consult your supplier. Frequently resetting these messages without remedying may damage the unit.

### Inputs menu

Tap the **Inputs** icon to enter the **Inputs** menu.



This menu shows information about all the inputs.

## Outputs menu

Tap the **Outputs** icon to enter the **Outputs** menu.



This menu shows information about all the outputs.



**Danger:**

Voltage-free outputs may only be used to control or monitor functional systems. They should **NOT** be used to control, switch or interrupt safety related circuits. Check the maximum allowed load on the label.




**Warning:**

Stop the unit and switch off the supply before connecting external equipment. Consult the safety precautions.

## Counters menu


Tap the **Counters** icon to enter the **Counters** menu.



This menu shows an overview of all actual hours and counters of the unit and controller.

## Auxiliary Equipment menu

Tap the **Auxiliary Equipment** icon to enter the **Auxiliary Equipment** menu.



This menu shows an overview of all auxiliary equipment fitted.

### 3.8 Service menu

#### Function

This screen is used to display the following submenus:

- **Service**
- **Service Functions** (visible as advanced user)
- **Clean Screen**


These submenus can be entered by tapping the icons.

#### Procedure

To enter the **Service** menu screen:

1. Tap the Menu button.
2. Tap the **Service** icon.

#### Description




85213

Reference	Description
(1)	<b>Service</b>
(2)	<b>Service Functions</b> (only visible as advanced user)
(3)	<b>Clean Screen</b>

#### Service menu

Tap the **Service** icon to enter the **Service** menu.



85211

This menu shows the remaining **Running Hours** and the remaining **Real Time Hours** until the next service. The first row (A) shows the **Running Hours** when the first service is needed (green), the second row shows the **Real Time Hours** (blue)

A service overview can be viewed by tapping icon (1).

The service plan can be viewed by tapping icon (2). Through this menu, the service plan can be modified:


1. Tap the desired service plan. A selection screen will pop up.
2. Change the Running Hours by tapping '–' or '+'.  
3. Confirm by tapping 'V' or decline by tapping 'X'.

The service history can be viewed by tapping icon (3).

When a service plan interval is reached, a message will appear on the screen. When service has been performed, the service timer can be reset by tapping the reset button (4).

### Service functions (visible for advanced user)


Tap the **Service Functions** icon to enter the **Service Functions** menu.



Depending on the machine, this menu can have a different set of functions. Many of them are password protected, as they are only accessible for authorized personnel.

### Clean screen

Tap the **Clean Screen** icon to start the 15 seconds countdown to perform cleaning of the touch screen.



The touch screen and the start and stop button become inactive for 15 seconds.

## 3.9 Week timer menu

### Function

This screen is used to set up to 4 different timers with each up to 8 settings per day.

The week timers can be activated through this screen.

A **Remaining Running Time** can be set from 5 up to 240 minutes.

### Procedure

To enter the **Week Timer** menu screen:

1. Tap the Menu button.
2. Tap the **Week Timer** icon.

**Description**



85214

Reference	Designation	Function
(1)	Add or select week	If less than 4 weeks are programmed, tap the '+' button to add a week.
(2)	Remove week	Tap to remove a programmed week timer.
(3)	Activate week timer	A selection screen pops up. The user can choose the correct week by tapping '-' or '+' and can confirm by tapping 'V' or decline by tapping 'X'.
(4)	Remaining running time	A selection screen pops up. The user can change the remaining time by tapping '-' or '+' and can confirm by tapping 'V' or decline by tapping 'X'.
(5)	Add setting	A selection screen pops up. The user can change the setting by swiping up or down and confirm by tapping 'V' or decline by tapping 'X'.

**3.10 Event history menu**

**Function**

This screen is used to display the saved data in case of an alarm.


These submenus can be entered by tapping the icons.

**Procedure**

To enter the **Event History** menu screen:

1. Tap the Menu button.
2. Tap the **Event History** icon.

**Description**



85216

Reference	Description
(1)	<b>Saved Data</b>

### Saved data

Tap the **Saved Data** icon to enter the **Saved Data** menu.

Scroll through the items swiping up and down in this list. The event date and time is shown at the right side of the screen.

Press on one of the items in the list for more information reflecting the status of the unit when the shutdown occurred.

## 3.11 Machine settings menu

### Function

This screen is used to display the following submenus:

- **Alarms**
- **Regulation**
- **Control Parameters**

Only visible if the machine has adaptable parameters.

- **Aux. Equipment Parameters**
- **Auto Restart**


These submenus can be entered by tapping the icons.

### Procedure

To enter the **Machine Settings** menu screen:

1. Tap the Menu button.
2. Tap the **Machine Settings** icon.

### Description




85222

Reference	Description
(1)	<b>Alarms</b> menu
(2)	<b>Regulation</b> menu
(3)	<b>Control Parameters</b> menu
(4)	<b>Aux. Equipment Parameters</b> menu
(5)	<b>Auto Restart</b> menu

## Alarms menu

Tap the **Alarms** icon to enter the **Alarms** menu.



85217

A list of all alarms is shown.

When pressing on one of the items in the underlying list, the warning and/or shutdown levels are shown for this alarm.

## Regulation menu

Tap the **Regulation** icon to enter the **Regulation** menu.



85218

Setpoints can be modified and capacity control can be consulted through this menu.

### Modify a setting


When tapping a list item, a selection screen pops up. The user can modify the setting by tapping ‘-’ or ‘+’ and can confirm by tapping ‘V’ or decline by tapping ‘X’.

### Change a selection

When tapping a list item, a selection screen pops up. The user can change the selection by swiping up or down and confirm by tapping ‘V’ or decline by tapping ‘X’.

## Control parameters menu

Tap the **Control Parameters** icon to enter the **Control Parameters** menu.



85219

This menu shows information about the **Control Parameters**.


### Modify a setting

When tapping a list item, a selection screen pops up. The user can modify the setting by tapping ‘-’ or ‘+’ and can confirm by tapping ‘V’ or decline by tapping ‘X’.



### Auxiliary equipment parameters menu

Tap the **Aux. Equipment Parameters** icon to enter the **Aux. Equipment Parameters** menu.



This menu shows an overview of all the auxiliary equipment fitted.


Through this menu, the parameters of the auxiliary equipment can be changed.

#### Modify a setting

When tapping a list item, a selection screen pops up. The user can modify the setting by tapping ‘-’ or ‘+’ and can confirm by tapping ‘V’ or decline by tapping ‘X’.

### Auto restart menu

Tap the **Auto Restart** icon to enter the **Auto Restart** menu.



Through this menu, the automatic restart can be activated. The activation is password protected.

The automatic restart settings can also be changed.

#### Enter a password

When tapping a password protected item, a selection screen pops up. The user can enter the password by swiping up or down to select the desired number. Once the 4 digits are entered, the user can confirm by tapping ‘V’ or decline by tapping ‘X’.

#### Modify a setting

When tapping a list item, a selection screen pops up. The user can modify the setting by tapping ‘-’ or ‘+’ and can confirm by tapping ‘V’ or decline by tapping ‘X’.

## 3.12 Controller settings menu

### Function

This screen is used to display the following submenus:

- **Network Settings**
- **Localisation**
- **User Password**
- **Help**

- **Information**


These submenus can be entered by tapping the icons.

**Procedure**

To enter the **Controller Settings** menu screen:

1. Tap the Menu button.
2. Tap the **Controller Settings** icon.

**Description**




85228

Reference	Description
(1)	<b>Network Settings</b> menu
(2)	<b>Localisation</b> menu
(3)	<b>User Password</b> menu
(4)	<b>Help</b> menu
(5)	<b>Information</b> menu

**Network settings menu**

Tap the **Network Settings** icon to enter the **Network Settings** menu.



85223

**Ethernet Settings**

The list of **Ethernet Settings** is shown. When ethernet is turned off, the settings can be modified.

**CAN Settings**

The list of **CAN Settings** is shown. When CAN is turned off, the settings can be modified.

**Modify a setting**


When tapping a list item, a selection screen pops up. The user can modify the setting by tapping '−' or '+' and can confirm by tapping 'V' or decline by tapping 'X'.

**Change a selection**

When tapping a list item, a selection screen pops up. The user can change the selection by swiping up or down and confirm by tapping 'V' or decline by tapping 'X'.

## Localisation menu

Tap the **Localisation** icon to enter the **Localisation** menu.



### Language

The language setting of the controller can be modified through this menu.

### Date/Time

The date and time settings of the controller can be modified through this menu.

### Units

The units displayed can be modified through this menu.

### Modify a setting


When tapping a list item, a selection screen pops up. The user can modify the setting by tapping '–' or '+' and can confirm by tapping 'V' or decline by tapping 'X'.

### Change a selection

When tapping a list item, a selection screen pops up. The user can change the selection by swiping up or down and confirm by tapping 'V' or decline by tapping 'X'.

## User password menu

Tap the **User Password** icon to enter the **User Password** menu.




The user password can be activated or deactivated through this menu. Enter and confirm a user password to activate, repeat to deactivate.

### Enter a password

When tapping a password protected item, a selection screen pops up. The user can enter the password by swiping up or down to select the desired number. Once the 4 digits are entered, the user can confirm by tapping 'V' or decline by tapping 'X'.

## Help menu

Tap the **Help** icon to enter the **Help** menu.




85226

This menu can show a link to the web page of your supplier, a helpdesk phone number or other helpful information.

### Information menu

Tap the **Information** icon to enter the **Information** menu.



85227

This menu shows information about the controller.

## 3.13 Access level


### Function

Through this pop-up screen, the access level settings can be viewed or changed.

### Procedure

The **Access Level** screen can be viewed or changed by tapping the **Access Level** button at the upper right corner of the screen.

### Description




85229

Reference	Designation	Function
(1)	User	A basic set of parameters is visualized, no password required.
(2)	Service	A basic set of parameters can be modified, no password required.
(3)	Full	This access level is not accessible to end users.
(4)	Decline	Tap to decline the selected user level.


Reference	Designation	Function
(5)	Confirm	Tap to confirm the selected user level.

### Service access level



85230

Tap the **Service** access level icon (1) and confirm (2).



85231

The screen information bar (1) now shows the current status of the unit instead of the machine serial number.

The Received Signal Strength Indicator (RSSI) value is now shown in the Internal SmartBox menu. See section *Quick access screen*.

In the service menu, an extra menu item is now available. See section *Service menu*.

## 4 Installation

### 4.1 Dimension drawings

The dimension drawing can be found in the technical documentation, supplied with the unit.

Model	Pressure variant (bar(e))	Model variant	Voltage (V)	Weight (kg)
GA 5 VSD <sup>s</sup>	10/13	Pack	380/400/460	240
			200/230	382
			500/575	336
		Full-Feature	380/400/460	330
			200/230	429
			500/575	383
		Pack, tank mounted	380/400/460	290
			200/230	440
			500/575	394
		Full-Feature, tank Mounted	380/400/460	398
			200/230	486
			500/575	440
GA 7 VSD <sup>s</sup>	10/13	Pack	380/400/460	242
			200/230	382
			500/575	336
		Full-Feature	380/400/460	291
			200/230	431
			500/575	385
		Pack, tank mounted	380/400/460	322
			200/230	429
			500/575	383
		Full-Feature, tank Mounted	380/400/460	389
			200/230	477
			500/575	431

Model	Pressure variant (bar(e))	Model variant	Voltage (V)	Weight (kg)
GA 11 VSD <sup>s</sup>	10	Pack	380/400/460	319
			200/230	479
			500/575	415
		Full-Feature	380/400/460	369
			200/230	547
			500/575	483
	Pack, tank mounted	380/400/460	409	
		200/230	525	
		500/575	461	
	Full-Feature, tank Mounted	380/400/460	477	
		200/230	593	
		500/575	547	
13	Pack	380/400/460	253	
		200/230	413	
		500/575	349	
	Full-Feature	380/400/460	303	
		200/230	481	
		500/575	417	
	Pack, tank mounted	380/400/460	343	
		200/230	459	
		500/575	395	
	Full-Feature, tank Mounted	380/400/460	411	
		200/230	527	
		500/575	481	
GA 15 VSD <sup>s</sup>	10	Pack	380/400/460	319
			200/230	527
			500/575	437
		Full-Feature	380/400/460	442
			200/230	602
			500/575	512
	13	Pack	380/400/460	253
			200/230	461
			500/575	371
		Full-Feature	380/400/460	376
			200/230	536
			500/575	446
GA 18 VSD <sup>s</sup>	10/13	Pack	380/400/460	328
			200/230	572
			500/575	452
		Full-Feature	380/400/460	452
			200/230	647
			500/575	527

**Table 1: Dimensions and weight**

## 4.2 Installation proposal

### Safety



**Warning:** The operator must apply all relevant safety precautions, including those mentioned in this manual.

- Read the manual before installing the compressor. The instruction book contains the necessary information regarding to the detailed values.
- Check the situation.
- Use the correct tooling.





Figure 21: Compressor room example







**Figure 22: Minimum service room**

**Foundation, placement of the compressor unit**

Install the compressor unit on a solid, level floor, suitable for the compressor mass. It is not allowed to place any extra (damping) material between the floor and the base frame so the frame is not supported on the complete surface.




Make sure enough space is available for proper maintenance and servicing. All dimensions can be found in the compressor room example in the drawing above.



**Transportation brackets**

Before starting the compressor for the first time, check that all red-colored transportation brackets/ bolts have been removed. They can be under the drivetrain, separation vessel and the compressor of the integrated dryer (optional).




## Electrical connections

- The supply voltage on the compressor terminals must not deviate more than 10% of the nominal voltage. It is highly recommended to keep the voltage drop over the supply cable at nominal current below 5% of the nominal voltage.
- Power supply cable must be sized and installed by a qualified electrician. Cable sizing examples according to IEC and UL can be found in the *Technical Data* section. If cables are grouped together with other power cables, it may be necessary to use cables of a larger size than those calculated for the standard operating conditions. Local regulations remain applicable if they are stricter than the values proposed.
- A main switch and fuses are not included in the compressor unit and should be foreseen externally by a qualified electrician. For selecting the correct fuse type and size, refer to the service diagram or the *Technical Data* section. Note that different sizes exist for compressors with or without integrated dryer.




- Always double-check the fuse size versus the calculated cable size. If required, reduce fuse size or enlarge cable size.
- To preserve the protection degree and to protect the components from dust from the environment, it is mandatory to use a well sealing cable gland when connecting the supply cable to the compressor.



- For VSD compressors, fast reacting fuses should be installed as mentioned in the instruction book. The use of circuit breakers is not allowed.
- Electric screw connections need to be checked and torqued before initial start-up. Torque values can be found on the service diagram.

## Condensate collection


The drain pipes to the drain collector may not dip into the water of the drain collector.



Oil/water separators are used to separate oil from the condensate to ensure that the condensate meets the requirements of the environmental codes. Drain pipes of the same or different compressors may not be interconnected before the (atmospheric) collector as this can damage the electronic drains.

**Ventilation**


The compressor room should have proper ventilation in order to keep the air inlet temperature of the compressor under control. The maximum air temperature at the compressor intake is 46°C (115°F), the minimum temperature is 0°C (32°F). If the room temperature exceeds any of these limits, the compressor will automatically shut down.



**Note:** If the unit is equipped with the option “High Ambient Version”, it is allowed to operate the unit up to 55°C (131°F). This option comes with Roto Synthetic Fluid XTEND DUTY oil filling. A compressor with the freeze protection option will shut down below -10°C (14°F).

The inlet grids, ducting and external ventilation fan should always be installed in such way that recirculation of cooling air to the integrated dryer and/or motor compartment is avoided. To prevent feedback of exhaust air into the cooling inlet, sufficient space should be foreseen above the unit to evacuate the exhaust air. Otherwise a duct for the exhaust air should be installed.

If ducting needs to be foreseen, a different cooling capacity may be required depending on the two alternative ducting configurations:



The direction of cooling flows may never be inverted.

The maximum air velocity through the ventilation grids is 5 m/s (16.5 ft/s). The maximum allowed pressure drop in ventilation ducts before or after the compressor is 20 Pa. If it exceeds this value, a fan is needed at the outlet of the ducts. When a duct is foreseen on the air inlet, the ambient temperature sensor needs to be repositioned in such way that the inlet temperature is correctly monitored.

Unit	Additional allowed pressure drop	Cooling air flow
GA 5 VSD <sup>S</sup>	30 Pa	0.83 m <sup>3</sup> /s
GA 7 VSD <sup>S</sup>	30 Pa	0.83 m <sup>3</sup> /s
GA 11 VSD <sup>S</sup>	30 Pa	0.83 m <sup>3</sup> /s
GA 15 VSD <sup>S</sup>	30 Pa	1.16 m <sup>3</sup> /s
GA 18 VSD <sup>S</sup>	30 Pa	1.16 m <sup>3</sup> /s

**Table 2: Duct sizing information**



**Note:** If the pressure drop of the ducting is too big to be overcome by the standard fan, it is recommended to equip the unit with the “Power Duct Fan” option. This option increases the total allowable pressure drop through the ducts without the need to install an additional external fan.

### For air-cooled compressors and ventilation alternative 1

The ventilation capacity required to limit the compressor room temperature can be calculated as follows:

- For compressors without dryer:

$$Q_v = 1.06 N / \Delta T$$

- For compressors with dryer:

$$Q_v = (1.06 N + 1.2 D) / \Delta T$$

$Q_v$  = required ventilation capacity in m<sup>3</sup>/s

$N$  = nominal power of the compressor motor in kW

$D$  = electric power of the dryer in kW

$\Delta T$  = temperature increase in the compressor room in C

### For air-cooled compressors and ventilation alternative 2

The fan capacity should match the compressor fan capacity at a pressure head equal to the pressure drop over the air ducts.

Make sure that the cooling air duct of the air/oil cooler is separated from the cooling air duct of the dryer.


### Air filtration

Filter DD to be installed for general-purpose filtration (particle removal down to 1 micron with a maximum oil carry-over of 0.5 mg/m<sup>3</sup>). A high-efficiency filter, type PD, may be installed downstream of a DD filter. This filter traps solid particles down to 0.01 micron with a maximum oil carry-over of 0.01 mg/m<sup>3</sup>. An UD+ filter leads to the same air purity as a DD filter combined with a PD. If oil vapor and odors are undesirable, a QD type filter can be installed downstream of the PD filter. All filters should be preceded by a water separator if no water separator is integrated in the after cooler of the compressor. In case a dryer is preceding the filter, a water separator is no longer required.

It is recommended to install bypass pipes with ball valves over each filter in order to isolate the filters during service operations without disturbing the compressed air delivery.

The condensate collecting tubes should have a minimum length of two meter before they are interconnected. After the interconnecting point, the drain tube requires twice the diameter of the original tubes.

It is not allowed to connect pressurized electronic drains on the draining tubes of the filters.



**Air delivery pipe**

The pressure drop over the air delivery pipe can be calculated from:

$$\Delta p = (L \times 450 \times Q_c^{1.85}) / (d^5 \times P)$$

d = inner diameter of the pipe in mm


$\Delta p$  = pressure drop in bar (recommended maximum: 0.1 bar (1.5 psi))

L = length of the pipe in m

P = absolute pressure at the compressor outlet in bar(a)

$Q_c$  = free air delivery of the compressor in l/s

It is recommended that the connection of the compressor air outlet pipe is made on top of the main air net pipe in order to minimize carry-over of possible condensate residue.



For proper maintenance, a manual controllable valve has to be installed on the compressed air outlet in order to isolate the compressor from the compressed air network.



## Air tank

Install the air tank (if purchased separately) in a frost free room and on a solid level floor, suitable for its mass.

The air tank must be fitted with a correctly sized and approved safety valve that is directly connected with the vessel. At the bottom of the vessel, a drain needs to be installed to collect the condensate.

For normal air consumption, the volume of the air net (tank and piping) can be calculated from:

$$V = (0.25 \times Q_c \times P_1 \times T_0) / (f_{\max} \times \Delta P \times T_1)$$

V = volume of the air net in l

$Q_c$  = free air delivery of the compressor in l/s

$P_1$  = compressor air inlet pressure in bar(a)

$f_{\max}$  = maximum cycle frequency (recommended: 1 cycle/30s)

$\Delta P$  = difference between unloading pressure and loading pressure in bar

$T_1$  = compressor air inlet temperature in K

$T_0$  = air tank temperature in K

## Moving/ lifting

The compressor can be moved by a lift truck using the slots in the frame. Take care not to damage the bodywork during lifting or transport. The transport bolts cannot be removed until the unit is on its fixed and final position. Reinstall these each time the unit is moved.

Make sure that the forks protrude the other side of the frame. The compressor can also be lifted after inserting beams in the slots. Make sure that the beams cannot slide and that they equally protrude the frame. The chains must be held parallel to the bodywork by chain spreaders in order not to damage the compressor. The lifting equipment must be placed in such a way that the compressor is lifted perpendicularly. Lift gently and avoid twisting.



**Warning:** In case of units equipped with the Lifting Device Option, it is not allowed to lift the compressor if the canopy parts or lifting supports are not completely installed. When the compressor is being lifted, it is forbidden to stand under the load or to perform maintenance activities on it.

## Outdoor/ altitude operation

Compressors can be sold with the option rain protection. With this, the compressor can be installed outside under a shelter, in frost free conditions.

If frost might occur, the appropriate measures should be taken to avoid damage to the machine and its ancillary equipment. In combination with the *Freeze Protection* option, the unit can start up in ambient temperatures down to minus 20°C (-4°F) and can run continuously at minus 10°C (14°F). This option comes with Roto Synthetic Fluid XTEND DUTY oil filling.

Maximum operating altitude of the unit is 1000m (3000ft).

## Quality of the intake air

The compressors intake air must be clean and free of solid and avoid gaseous contamination. Particles of dirt that cause wear and corrosive gases (SO<sub>2</sub>, NO<sub>x</sub>, chlorides, H<sub>2</sub>S, NH<sub>3</sub>, etc.) can be

particularly damaging. Care must be taken to minimize the entry of moisture\* at the inlet air. No water droplets should enter the air intake.

100% RH	35°C (95°F)
70% RH	40°C (104°F)
30% RH	46°C (115°F)

**Table 3: Maximum acceptable relative humidity per ambient temperature**

### Use of generators and transformers

When installing the compressor connected to a generator or transformer, it is commended to have at least the indicated power available per compressor. If the generator or transformer is smaller then this recommendation, detailed calculations can be made to ensure the strength of the grid.

Please contact your supplier for more details on calculations (document reference 2646 2357 00).

## 4.3 Electrical connections



**Danger:** Working with machinery controlled by a frequency converter requires special safety precautions.

These safety precautions depend on the kind of network used (TN, TT, IT system). Consult your supplier.




**Note:** Most compressors are designed for use in TT/TN networks and are intended for industrial environments where the electrical supply is separated from the residential/commercial supply network.


To use the machine in light industrial, commercial or residential environments with a shared supply network or in an IT network, additional measures may be required. Contact your supplier.

### IT Network

In case you have an IT earthing system, remove bolt (1), indicated in the picture below.



## Electrical connections




87348


Reference	Description
(1)	Customer's installation
(2)	Power circuit
(3)	Motor

The complete electrical diagram can be found in the technical documentation, supplied with the unit.

### Description

 **Note:** You can find the correct position for the electrical connections in the section *Dimension drawings*.

1. Provide an isolating switch.
2. Check that the motor cables and wires inside the electric cabinet are clamped tight to their terminals.
3. Check the fuses. See section *Electric cable size and fuses*.
4. Connect the power supply cables to the terminals of the Neos Next.
5. Connect the earth conductor to the earth bolt (PE).

 **Note:** To preserve the protection degree of the electric cubicle and to protect its components from dust from the environment, it is mandatory to use a proper cable gland when connecting the supply cable to the compressor.

### Compressor control modes

The following control modes can be selected:

- **Local control:** The compressor will react to commands entered by means of the buttons on the control panel. Compressor start/stop commands via Clock function are active, if programmed.



- **Remote control:** The compressor will react to commands from external switches. Emergency stop remains active. Compressor start/stop commands via Clock function are still possible.



**Note:** Have the modifications checked by your supplier.

Stop the compressor and switch off the voltage before connecting external equipment.

Only potential free contacts are allowed.

- **LAN control:** The compressor is controlled via a local network. Contact your supplier.


**Compressor status indication**

The controller is provided with potential free auxiliary NO contacts (NO = normally open) for remote indication of:

- Manual or automatic operation
- Warning condition
- Shutdown condition

Stop the compressor and switch off the voltage before connecting external equipment. Contact your supplier.

**4.4 Pictographs**



**Figure 23: Pictographs**

Reference	Description
1	Lock out, tag out the compressor before starting maintenance or repairs
2	Automatic condensate drain
3	Manual condensate drain
4	Lightly oil the gasket of the oil filter, screw it on and tighten by hand (approximately half a turn)
5	Automatic restart after voltage failure (ARAVF)
6	Stop the compressor before cleaning the coolers
7	Warning, voltage
8	Switch off the voltage and wait at least 10 minutes before maintenance
9	Compressor remains pressurized for 180 seconds after switching off the voltage

Reference	Description
10	Keep doors closed during operation
11	Cooling water inlet (option energy recovery)
12	Cooling water outlet (option energy recovery)
13	Electronic water drain (EWD) installation
14	Hot surface

## 4.5 Instructions for prolonged storage

### Procedure

Run the compressor regularly, e.g. twice a week, until warm.



**Note:** If the compressor is going to be stored without running from time to time, protective measures must be taken. Consult your supplier.

## 5 Energy recovery

### 5.1 Energy recovery (ER) unit

#### Description

A large part of the energy required for any compression process is transformed into heat. The major part of the compression heat is dissipated through the oil system. Energy recovery (ER) systems are designed to recover most of this heat by transforming it into warm or hot water without any adverse effects on compressor performance. The water can be used for diverse applications.

#### Components

The energy recovery (ER) system is completely integrated and comprises the following:

- Stainless steel oil/water heat exchanger
- Thermostatic by-pass valve for energy recovery heat exchanger (BV2)
- The necessary bolts, pipes, etc.
- Oil drain valve

#### Energy recovery (ER) unit




Figure 24: Main components

Reference	Description
1	Water inlet pipe
2	Water outlet pipe

Reference	Description
V1	Valve 1
V2	Valve 2
V3	Valve 3
BV2	Thermostatic bypass valve
OV	Overpressure valve
HE	Heat exchanger
D	Oil drain valve

## Field installation

The main components are assembled ex-factory as a compact unit which fits inside the bodywork of the compressor. Consult your supplier for installing and connecting the energy recovery (ER) unit.

## 5.2 Energy recovery (ER) systems

### General

The energy recovery (ER) systems can be applied as low temperature rise/high water flow systems or as high temperature rise/low water flow systems.

### Low temperature rise/high water flow systems

For this type of application, the temperature difference between the water in the energy recovery (ER) system and the compressor oil is low. As a consequence, a high water flow is needed for maximum energy recovery.

Example: The heated water is used to keep another medium at a moderately high temperature, in a closed circuit, e.g. central heating.

### High temperature rise/low water flow systems

For this type of application, a high water temperature rise in the energy recovery (ER) system is obtained, which consequently brings on a low flow rate.

Example: An open circuit where cold water from a main supply is heated by the energy recovery (ER) system for use in a factory, e.g. pre-heating of boiler feed water.

### Recovery water flow

The recovery water enters the unit at the inlet connection (1). The compression heat is transferred from the compressor oil to the water in the heat exchanger (HE). The water leaves the heat exchanger (HE) via the outlet connection (2).

### Water requirements for closed water circuits

The use of a closed water circuit minimizes supplementary water requirements. Therefore, the use of soft or even demineralized water is economically feasible and eliminates the problem of scale deposits. Although the heat exchanger is made of stainless steel, the water circuit connected to the compressor may require corrosion inhibitors.

Add an anti-freeze product such as ethylene-glycol to the water in proportion to the expected temperature to avoid freezing.

### Water requirements for open water circuits

In open, non-recirculating water circuits, major problems that are usually encountered are related to deposit control, corrosion control, and microbiological growth control. To minimize these problems, the water that is being used should meet a number of requirements.

## 5.3 Energy recovery (ER) operation

### Description

The compressor oil flow is controlled by a Smart Temperature Control (STC) valve, ensuring reliable compressor operation and optimum energy recovery.

The Smart Temperature Control (STC) valve is integrated in the oil filter housing of the compressor and controls the oil flow to the oil/water heat exchanger (HE) of the compressor. The thermostat valve in the external housing behind the energy recovery (ER) heat exchanger, controls the oil flow through the main cooler (CO) of the compressor.




Figure 25: Unit with energy recovery (ER) system

Reference	Description
HE	Oil/water heat exchanger
E	Compressor element
OF	Oil filter
AR	Oil separator vessel
STC	Smart Temperature Control valve
Co	Oil cooler
Ca	Aftercooler
1	Water inlet
2	Water outlet

The Smart Temperature Control (STC) valve starts directing the oil flow to the oil/water heat exchanger as soon as the compressor temperature is sufficiently high to avoid condensate formation and recover energy. Unlike a standard thermostat the temperature setpoint is variable, this to optimize the amount of recovered energy. When the cooling of the oil/water heat exchanger becomes insufficient the BV starts opening, causing oil to flow through the main cooling module (Co) as well.

The energy recovery (ER) system is provided with bypass valves on the water side, which can be found on the backside of the unit. In order to bypass the water flow valve 1 and 2, should be closed and valve 3 should be opened.




Figure 26: Energy recovery (ER) label



**Warning:** It is NOT allowed to use the ball valves at an in-between position!

### Energy recovery (ER) system in use

Bypass valves in position (A): the heat exchanger (HE) is integrated in the water side of the energy recovery (ER) system (see drawing).

- Compressor start-up

When the compressor is started up from cold, the oil temperature will be low. The Smart Temperature Control (STC) valve shuts off the oil supply to the oil cooling system to prevent the compressor oil from being cooled. The oil flows from the oil separator vessel (AR) through the oil filter(s) (OF) back to compressor element (E).

All energy input is used to rapidly warm up the compressor oil. No energy is recovered.

- Maximum energy recovery

As soon as the oil temperature reaches the set point (opening temperature) of the Smart Temperature Control (STC) valve, the valve starts closing off the bypass over the oil cooling system, gradually allowing the oil to flow through the heat exchanger (HE). As the ambient conditions (temperature and humidity) allow the cooling of the compressor oil, all the oil passes through the cooling system. The exchange of heat between the compressor oil and the heat recovery water is maximum at 75°C (167 °F) oil temperature. The oil from the heat exchanger outlet flows via oil filter (OF), compressor element (E) and separator (AR) back to the inlet of heat exchanger (HE).

The bypass valve bypasses the main oil cooler (Co) as long as the oil temperature remains below its set point of 75°C.

## Stopping the unit for a long period

In case of an open water system and/or if freezing temperatures can be expected, isolate the compressor water system and blow it through with compressed air.

## 5.4 Energy recovery (ER) maintenance

### Compressor oil

For references used consult section *Energy recovery (ER) unit*.

#### Oil change:

1. Run the unit until warm. Stop the unit, switch off the isolating switch and close the air outlet valve of the compressor.
2. Depressurize the compressor and drain the oil by opening the drain valve. Also drain the oil from the heat exchanger by opening the drain valve on the heat exchanger (HE). Close the valve after draining.
3. Resume oil change as described in section *Oil, oil filter and oil separator change* in this book.

### Smart Temperature Control (STC) valves

Change the thermostat of the energy recovery (ER) system at the same interval as the thermostat of the unit.

### Heat exchanger (HE)

If the temperature rise over the energy recovery (ER) system declines over a period of time with the same basic working conditions, the heat exchanger should be inspected. To clean the oil side, soak the heat exchanger in a degreasing solution. To remove scale formation in the water compartment, a proper descaling process should be applied. Consult your supplier.

## 5.5 Energy recovery (ER) cooling water requirements

### General



**Note:** Cooling water needs to fulfill certain requirements in order to avoid problems of scaling, fouling, corrosion or bacterial growth.

In open circuit cooling towers, protective measures must be taken to avoid the growth of harmful bacteria such as legionella pneumophila when there is a risk of inhalation of the water droplets.

No general recommendation can encompass the effects of all combinations of the various compounds, solids and gases typically found in cooling water in interaction with different materials. Therefore, the recommendations formulated in our Cooling Water Specifications are a general guideline for acceptable coolant quality. However, where strict limits apply, a statement is made in the specification.

The water requirements refer to untreated water. When water is treated, some parameters will change. Water treatments should be carried out by a specialized water treatment company, taking the responsibility for the performance of the treated cooling water and the compatibility with the materials in the cooling circuit. This includes not only the selection of the appropriate additives, but also the correct application, monitoring of concentrations and properties, prevention of sludge formation and maintenance of the system. This applies also to treatment with antifreeze products.

They must be provided with suitable stabilizers and inhibitors. Specifications are also depending on the type of cooling circuit (open, once through / recirculating with tower / closed) and on the application (Standard – max 65 °C cooling water temperature at the outlet) or energy recovery (water temperature up to 95 °C).

In case water is not in line with recommended values or if any doubt, consult the manufacturer.

## Cooling water parameters

### 1. pH

The effect of pH is already included in the Ryznar Stability Index (RSI - see item 4 below), but also the pH itself is subject to limitations:

Type of cooling system	Materials	pH	
		Standard	Energy recovery (ER)
Single pass	Containing copper	<b>6.8 - 9.3</b>	<b>6.8 - 9.3</b>
	Stainless steel with carbon steel and / or cast iron	<b>6.8 - 9.3</b>	<b>6.8 - 9.3</b>
	Stainless steel only	<b>6 - 9.3</b>	<b>6 - 9.3</b>
Recirculating (with tower)	Containing copper	<b>6.8 - 9.3</b>	not applicable
	Stainless steel with carbon steel and / or cast iron	<b>6.8 - 9.3</b>	
	Stainless steel only	<b>6 - 9.3</b>	
Closed loop	Containing copper	<b>7.5 - 9.3</b>	<b>7.5 - 9.3</b>
	Stainless steel with carbon steel and / or cast iron	<b>7.5 - 9.3</b>	<b>7.5 - 9.3</b>
	Stainless steel only	<b>6 - 9.3</b>	<b>6 - 9.3</b>

The values in **bold** are rejection limits.

When the system contains Zn or Al, the pH must be < 8.5.

### 2. Total dissolved solids (TDS) and conductivity

The conductivity is expressed in  $\mu\text{S}/\text{cm}$ , the TDS in ppm.

Both parameters are related with each other. The conductivity is convenient for quick monitoring of general water quality, but the TDS is required for calculating the RSI. If only one of both parameters is measured, an estimation can be obtained by using a theoretical conversion factor (0.67):

$$\text{TDS} = \text{conductivity} \times 0.67$$

### 3. Hardness

Different types of hardness are in relation with each other and together with the pH and the alkalinity of the water they determine the equilibrium situation of the water, determined and specified by the RSI.

In addition, the calcium hardness must be limited to:



Type of cooling system	Ca (ppm Ca CO <sub>3</sub> )	
	Standard	Energy recovery (ER)
Single pass	< 500	< 2
Recirculating (with tower)	< 500	not applicable
Closed loop	< 1000	< 50

#### 4. The Ryznar Stability Index (RSI)

The Ryznar Stability Index is a parameter for predicting whether water will tend to dissolve or precipitate calcium carbonate. The adhesion of scaling depositions and their effect are different on different materials, but the equilibrium of the water (scaling or corrosive) is only determined by its actual pH value and by the saturation pH value (pH<sub>s</sub>). The saturation pH value is determined by the relationship between the calcium hardness, the total alkalinity, the total solids concentration and the temperature.

The Ryznar Stability Index is calculated as follows:

$$RSI = 2 \cdot pH_s - pH,$$

in which

- pH = measured pH (at room temp) of the water sample
- pH<sub>s</sub> = pH at saturation

pH<sub>s</sub> is calculated from:

$$pH_s = (9.3 + A + B) - (C + D),$$

in which

- A : depends on the total solids concentration
- B : depends on the water temperature at the outlet of the heat exchanger
- C : depends on the calcium hardness (CaCO<sub>3</sub>)
- D : depends on the HCO<sub>3</sub><sup>-</sup> concentration or M-alkalinity

The values of A, B, C and D can be found in below table:

Total dissolved solids (mg/l)	A	Temperature (°C)	B	Ca hardness (ppm CaCO <sub>3</sub> )	C	M-Alkalinity (ppm CaCO <sub>3</sub> )	D
< 30	0.1	0 - 1	2.3	9 - 11	0.6	10 - 11	1.0
30 - 320	0.2	2 - 6	2.2	12 - 14	0.7	12 - 14	1.1
> 320	0.3	7 - 11	2.1	15 - 17	0.8	15 - 17	1.2
		12 - 16	2.0	18 - 22	0.9	18 - 22	1.3
		17 - 22	1.9	23 - 28	1.0	23 - 28	1.4
		23 - 27	1.8	29 - 35	1.1	29 - 35	1.5
		28 - 32	1.7	36 - 44	1.2	36 - 44	1.6
		33 - 38	1.6	45 - 56	1.3	45 - 56	1.7
		39 - 43	1.5	57 - 70	1.4	57 - 70	1.8
		44 - 49	1.4	71 - 89	1.5	71 - 89	1.9
		50 - 55	1.3	90 - 112	1.6	90 - 112	2.0
		56 - 61	1.2	113 - 141	1.7	113 - 141	2.1

Total dissolved solids (mg/l)	A	Temperature (°C)	B	Ca hardness (ppm CaCO <sub>3</sub> )	C	M-Alkalinity (ppm CaCO <sub>3</sub> )	D
		62 - 67	1.1	142 - 177	1.8	142 - 177	2.2
		68 - 73	1.0	178 - 223	1.9	178 - 223	2.3
		74 - 79	0.9	224 - 281	2.0	224 - 281	2.4
		80 - 85	0.8	282 - 355	2.1	282 - 355	2.5
		86 - 91	0.7	356 - 446	2.2	356 - 446	2.6
		92 - 95	0.6	447 - 563	2.3	447 - 563	2.7
				564 - 707	2.4	564 - 707	2.8
				708 - 892	2.5	708 - 892	2.9
				893 - 1000	2.6	893 - 1000	3.0

#### Interpretation of the values obtained:

- RSI < 6: boiler scale formation
- 6 < RSI < 7: neutral water
- RSI > 7: corrosive water



**Note:** As a general rule, the RSI index should be between 5.6 and 7.5. If that is not the case, contact a specialist.

#### 5. Free chlorine (Cl<sub>2</sub>)

Disinfecting with chlorine is **not done in closed systems, neither in energy recovery (ER) systems.**

A continuous level of 0.5 ppm should not be exceeded. For shock treatments, a maximum limit of 2 ppm for maximum 30 minutes/day applies.

#### 6. Chlorides (Cl<sup>-</sup>)

Chloride ions will create pitting corrosion on stainless steel. Their concentration should be limited, depending from the RSI value.

	RSI < 5.5	5.6 < RSI < 6.2	6.3 < RSI < 6.8	6.9 < RSI < 7.5	7.6 < RSI
Cl <sup>-</sup> (ppm)	200	350	500	350	200

For energy recovery (ER) systems, the limit is 100 ppm.

#### 7. Sulphates (SO<sub>4</sub><sup>2-</sup>)

Type of cooling system	Sulphate (ppm)	
	Standard	Energy recovery (ER)
Single pass	< 1000	< 200
Recirculating (with tower)	< 1000	not applicable
Closed loop	< 400	< 200

#### 8. Iron and Manganese

Type of cooling system	Dissolved iron (ppm)		Dissolved manganese (ppm)	
	Standard	Energy recovery (ER)	Standard	Energy recovery (ER)
Single pass	< 1	< 0.2	< 0.2	< 0.05
Recirculating (with tower)	< 1	not applicable	< 0.2	not applicable
Closed loop	< 1	< 0.2	< 0.2	< 0.05

The values in **bold** are rejection limits.

**9. Copper**

Type of cooling system	Copper (ppm)	
	Standard	Energy recovery (ER)
Single pass	< 1	< 0.2
Recirculating (with tower)	< 1	not applicable
Closed loop	< 1	< 0.2

**10. Ammonium**

The limit of **0.5 ppm** is a rejection limit.

The limitation only applies for copper containing systems.

**11. Suspended solids**

Large particles (size > 10 µm) should not be present as they can be filtered out.

Small particles (< 0.5 µm) are not taken into account.

For particles between 0.5 µm and 10 µm, the following limits apply:

Type of cooling system	Suspended solids (ppm)	
	Standard	Energy recovery (ER)
Single pass	< 10	< 1
Recirculating (with tower)	< 10	not applicable
Closed loop	< 10	< 1

**12. Oil or grease**

< **1 ppm** (rejection value)

**13. Bacteria**

If bacteria are present, they must be aerobic. Anaerobic bacteria (in closed systems) must be avoided.

Type of cooling system	Biology (CFU/ml)	
	Standard	Energy recovery (ER)
Single pass	< 10 <sup>5</sup> / < 10 <sup>7</sup>	< 10 <sup>3</sup> / < 10 <sup>5</sup>
Recirculating (with tower)	< 10 <sup>5</sup> / < 10 <sup>7</sup>	not applicable
Closed loop	< 10 <sup>3</sup> / < 10 <sup>5</sup>	< 10 <sup>3</sup> / < 10 <sup>5</sup>

The table shows the recommended values. The values in **bold** are rejection limits.



**Note:** If additives are used in the cooling water, take into account that the cooling capacity will change.

$$\Delta m = ((C_{pw} - C_{pa}) * X) / (C_{pw} * (1-X) + X * C_{pa}) * 100 \%$$

with

$\Delta m$ : change of mass flow of the coolant

$C_{pw}$ : specific heat capacity of water

$C_{pa}$ : specific heat capacity of the additives

X: the percentage of additives

## 5.6 Energy recovery (ER) data

### Reference conditions

See section *Reference conditions and limitations*.

### Effective working pressure

See section *Compressor data* for the normal working pressure.

### Maximum allowed pressure of the heat exchanger

Oil side	15 bar (217 psi)
Water side	10 bar (145 psi)

### Pressure drop

Water flow (l/min)	Pressure drop (Bar)	
	Pack	Full-Feature
10.4	0.04758	0.05502
15	0.09941	0.11348
20	0.18711	0.21146
25	0.29079	0.32823
30	0.42447	0.47777
35	0.57109	0.64353
38	0.66440	0.74889

Pressure drop equation	
Pack	Full-Feature
$dp = 0.0004 * Q^{2.0441}$	$dp = 0.0005 * Q^{2.028}$
dp (Bar)	
Q (l/min)	
Valid between 10-38 l/min	

### Reading settings

In addition to other data, the following temperatures can be read on the controller display:

#### For air-cooled units:

- The water inlet temperature of the energy recovery system
- The water outlet temperature of the energy recovery system

### Modifying settings

If the programmed warning settings for the water temperatures are exceeded, a warning indication is shown on the controller:

Temperature input		Minimum setting	Nominal setting	Maximum setting
Water inlet temperature of energy recovery	°C	0	70	99
Water inlet temperature of energy recovery	°F	32	158	210
Energy recovery water outlet temperature	°C	0	90	99
Energy recovery water outlet temperature	°F	32	194	210

To modify a setting, consult the relevant section in the description of the controller.

### Recoverable energy

The recoverable energy can be calculated by using the following formula:

$$\text{RECOVERED ENERGY (kW)} = 4.2 \times \text{water flow (l/s)} \times \text{water temperature rise (°C)}$$

The maximum recoverable energy is approx. 75 - 80% of shaft power of the compressor.

If you compare with the electrical input power the percentage will be lower for air cooled compressors because the fan requires also some electrical energy which is not recoverable.

For VSD compressors the recoverable energy is also a little lower because the drive also requires some electrical energy which is not recoverable.

### Data for low temperature rise/high water flow systems

In the tables below, typical values are given for the above mentioned type of water flow system.

Parameter	Unit	GA 5 VSD <sup>s</sup>	GA 7 VSD <sup>s</sup>	GA 11 VSD <sup>s</sup>	GA 15 VSD <sup>s</sup>	GA 18 VSD <sup>s</sup>
		7 bar 4500 rpm	7 bar 5400 rpm	7 bar 4600 rpm	7 bar 5850 rpm	7 bar 7600 rpm
Recoverable energy	kW	5.54	7.09	10.31	13.50	18.23
Recoverable energy	hp	6.17	9.64	14.03	18.36	24.79
Water flow	l/min	6.51	10.17	14.80	19.38	26.16
Water flow	cfm	0.23	0.36	0.52	0.68	0.92
Temperature at inlet	°C	50	50	50	50	50
Temperature at inlet	°F	122	122	122	122	122
Temperature at outlet	°C	60	60	60	60	60
Temperature at outlet	°F	140	140	140	140	140
Power rating	kW	5.5	7.5	11	15	18

Parameter	Unit	GA 5 VSD <sup>s</sup> 7 bar 4500 rpm	GA 7 VSD <sup>s</sup> 7 bar 5400 rpm	GA 11 VSD <sup>s</sup> 7 bar 4600 rpm	GA 15 VSD <sup>s</sup> 7 bar 5850 rpm	GA 18 VSD <sup>s</sup> 7 bar 7600 rpm
Water flow	kJ/kgK	4.18	4.18	4.18	4.18	4.18

#### Data for high temperature rise/low water flow systems\*

In the tables below, typical values are given for the above mentioned type of water flow system.

Parameter	Unit	GA 5 VSD <sup>s</sup> 7 bar 4500 rpm	GA 7 VSD <sup>s</sup> 7 bar 5400 rpm	GA 11 VSD <sup>s</sup> 7 bar 8400 rpm	GA 15 VSD <sup>s</sup> 7 bar 9150 rpm	GA 18 VSD <sup>s</sup> 7 bar 7600 rpm
Recoverable energy	kW	4.84	7.56	11.00	14.40	19.44
Recoverable energy	hp	6.58	10.28	14.96	19.58	26.44
Water flow	l/min	1.74	2.71	3.95	5.17	6.98
Water flow	cfm	0.06	0.10	0.14	0.18	0.25
Temperature at inlet	°C	20	20	20	20	20
Temperature at inlet	°F	68	68	68	68	68
Temperature at outlet	°C	60	60	60	60	60
Temperature at outlet	°F	140	140	140	140	140
Power rating	kW	5.5	7.5	11	15	18
Water flow	kJ/kgK	4.18	4.18	4.18	4.18	4.18

\* Please keep in mind that this type of application can have negative effect on the compressor performance.

## 6 Operating instructions

### 6.1 Initial start-up




**Warning:** The operator must apply all relevant safety precautions. Also consult section *Problem solving*.



**Note:** For the location of the air outlet valve and the drain connections, see sections *Introduction* and *Condensate system*.

1. Remove the canopy panel(s) in order to get access to the internal components.  
Remove the transport spacers.



2. Remove the volatile corrosion inhibitor (VCI) plates.
3. Check that the electrical connections correspond to the local codes and that all wires are clamped tight to their terminals.

The installation must be earthed and protected against short circuits by fuses of the inert type in all phases. An isolating switch must be installed near the compressor. Re-tighten the connections according to the service diagram before start-up.

4. Check the voltage selecting wires at the primary side of transformer T1.
5. Fit air outlet valve (AV). See section *Introduction* for the position of the valve.

Close the valve.

Connect the air net to the valve.

6. Fit the manual condensate drain valve (Dm).



Close the valve.

7. Check the oil level. The oil level should reach the bottom of the oil filler neck (FC).





Figure 27: Low pressure variant





**Figure 28: High pressure variant**

Minimum level should reach the oil sight glass (GI) when the compressor is stopped.

If needed, top up the oil.

Take care that no dirt drops into the oil system.

Refit and tighten the filler plug (FC).

**8.** Provide labels, warning the operator that:

- The compressor may automatically restart after voltage failure (if activated, consult your supplier).
- The compressor is automatically controlled and may be restarted automatically.
- The compressor may be remotely controlled.

**9.** Switch on the voltage.

On Full-Feature compressors: switch on the voltage and check the rotation direction of the dryer fan, this is an indication of the rotation direction of the dryer compressor.

Rotation arrows, visible through the grating in the roof, are provided on the plate below the fan to indicate the correct rotation direction of the fan motor.

**10.** On compressors with optional energy recovery system, drain valves, shut-off valves and a regulating valve should be fitted by the customer in the cooling water piping.

**11.** Open the air outlet valve.

Start and run the compressor for a few minutes. Check that the compressor operates normally.

## 6.2 Starting



Figure 29: Control panel

1. Open the air outlet valve.
2. Switch on the voltage. Check that voltage on LED (5) lights up.
3. Press start button (7) on the control panel. The compressor starts running and the automatic operation LED (4) lights up.

## 6.3 During operation



**Note:** Keep the panels closed during operation.



**Danger:** When the motors are stopped and the automatic operation LED is alight, the motors may start automatically.



**Warning:** When the automatic operation LED is lit, the regulator is automatically controlling the compressor, i.e. loading, unloading, stopping of the motors and restarting!

1. Check the oil level daily.


A few minutes after stopping, the oil level should reach the bottom of the oil filler neck (FC).

If the oil level is too low, wait until the compressor has depressurized. Push the emergency stop button to avoid the compressor to start unexpectedly. Next, close the air outlet valve and open the manual drain valve (Dm) until the air system between oil separator/air receiver vessel and outlet valve is fully depressurized. See section *Condensate system* for location of the outlet valve and water drain.


Unscrew oil filler plug (FC) one turn to permit any pressure left in the system to escape. Wait a few minutes. Remove the plug and add oil until the level reaches the filler opening. Fit and tighten the plug (FC).

Unlock the emergency stop button, select the STOP icon on the display and press reset before restarting.

Regularly check that condensate is discharged during operation. See section *Condensate system*. The amount of condensate depends on environmental and working conditions.



**Figure 30: Low pressure variant**



**Figure 31: High pressure variant**

**2. Regularly check the controller display.**

Check the display (1) regularly for readings and messages. The display normally shows the compressor outlet pressure, while the status of the compressor is indicated by means of a number of icons. Remedy the trouble (see section *Problem solving*) if alarm LED (2) is lit or flashes, see section *Icons used*. The display (1) will show a service message if a service plan interval has been exceeded or if a service level for a monitored component has been exceeded. Carry out the service actions of the indicated plans or replace the component and reset the relevant timer, see section *Service menu*.



## 6.4 Stopping

1. Press stop button on the control panel. Automatic operation LED goes out and the compressor stops.
2. Close the air outlet valve.
3. Press the test button on top of the electronic water drain(s) to the depressurize the piping between air receiver and outlet valve, next open the manual drain valve (Dm). See section *Condensate system*.
4. Switch off the voltage.
5. On compressors with optional energy recovery system:
  - Close the cooling water inlet valve.
  - If freezing temperatures can be expected, drain the cooling system completely.



**Warning:** To stop the compressor in the event of an emergency, press the emergency stop button. Alarm LED flashes.

- Remedy the problem cause.
- Next, unlock the button by pulling it out.
- Next, navigate to the Stop icon on the display by means of the navigation keys (3/4) and press the Select key.
- Press Reset.

Do not use the emergency stop button for normal stopping!

## 6.5 Taking out of operation

1. Disconnect the compressor from the mains.
2. Unscrew the oil filler plug only one turn to permit any pressure in the system to escape.
3. Shut off and depressurize the part of the air net which is connected to the outlet valve. Disconnect the compressor air outlet pipe from the air net.
4. Drain the oil.
5. Drain the condensate circuit and disconnect the condensate piping from the condensate net.
6. On compressors with optional energy recovery system:

- Isolate and disconnect the water system from the cooling water net.
- Drain the water circuit.

## 6.6 Boostflow

The unit comes with Boostflow Mode, allowing you to temporarily stretch the limit of your compressor without negative operational or reliability consequences. The extra boost delivers 5% more flow for a total period of 100 hours throughout the entire lifetime of the compressor.


The Boostflow feature improves the flexibility of a unit to provide the needed flow to the air net. No additional action is needed from end users, the function is as standard enabled and will automatically activate if needed.

The **Boostflow active** warning shows that the feature has been activated. This means that the unit has to compensate for a higher demand from the production process.

In practice, this feature increases the flow of the unit. Note however that there is a limit of 100 hours to the use of it. Therefore, in case the feature gets activated, we suggest contacting your supplier. They will help you investigate what is needed to guarantee everything is sized correctly in the air net to maintain the production process at the optimal level.

Please note that under certain conditions boostflow is not allowed to start. If, for example, the ambient temperature is too high; this is to protect the machine from damage.


In case you do not want to use this feature, you have the option to switch this off by tapping the **Boostflow** icon on the controller display. However we do not recommend disabling it as it will prevent your machine from optimally providing your required flow rate.



Reference	Description
1	Boostflow enabled
2	Boostflow disabled

When tapping the icon you will see a pop up selection box where a selection between 2 modes can be made:

- Standard mode: the unit will never increase the flow beyond its nominal capacity.
- Boost mode: if a higher flow of air is needed and the ambient conditions are within the allowable limits, the unit will increase its flow.



86426

## 7 Maintenance

### 7.1 Preventive maintenance schedule



**Warning:** Before carrying out any maintenance, repair work or adjustments, proceed as follows:

- Stop the compressor.
- Close the air outlet valve.
- Open the condensate drain valve to depressurize the air system between air receiver and outlet valve.
- Press the emergency stop button.
- Switch off the voltage. Lock Out and Tag Out (LOTO).
- Wait 5 minutes for the vessel to depressurize.
- Wait 10 minutes for the converter capacitors to discharge before starting any electrical checks, work and/or repair.

For detailed instructions, see section *Problem solving*.

The operator must apply all relevant safety precautions.

#### Warranty - Product Liability

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.

#### Service kits

For overhauling or carrying out preventive maintenance, service kits are available. See section *Service kits*.

#### Service agreements

A range of service agreements are available to suit your needs :

- Inspection Plan
- Preventive Maintenance Plan
- Warranty+ Plan
- Total Responsibility Plan

Contact your supplier to set up a tailor-made service agreement. It will ensure optimum operational efficiency, minimize downtime and reduce the total life cycle cost.

#### General

When servicing, replace all removed O-rings and washers.

#### Intervals

The local Customer Center may overrule the maintenance schedule, especially the service intervals, depending on the environmental and working conditions of the compressor.

The longer interval checks must also include the shorter interval checks.

## Service plans

Besides the daily and 3-monthly checks, preventive maintenance actions are specified in the schedule below.

Each plan has a programmed time interval at which all service actions belonging to that plan are to be carried out. When reaching the interval, a message will appear on the screen indicating which service plans are to be carried out. After servicing, the intervals must be reset, see section *Service menu*.

## Preventive maintenance schedule

Period	Action
Daily	Check oil level. If needed, top up the oil. See section <i>During operation</i> . Check readings on display. Check that condensate is discharged by waiting for some time during operation. You can use the test button on top of the electronic water drain to check the drain function.
Monthly <sup>(1)</sup>	Check and clean the relative humidity sensor. See section <i>RH sensor</i> .
3-monthly <sup>(1)</sup>	Check coolers, clean if necessary. Remove the air filter element and inspect. Replace damaged or heavily contaminated elements. Check the filter elements of the electric cabinet. Replace if necessary. Clean the NEOS Next heat sink with a vacuum cleaner.

**Table 4: Checklist for compressors**

Period	Action
Daily	Check that condensate is discharged by the dryer drain by waiting for some time during operation. You can use the test button on top of the electronic water drain to check the drain function.
Monthly <sup>(1)</sup>	Condenser cleaning: <ul style="list-style-type: none"> <li>• Stop the compressor, close the air outlet valve and switch off the voltage.</li> <li>• Remove any dirt on the condenser inlet with a vacuum cleaner.</li> <li>• Next, clean with an air jet in the reverse direction to normal flow. Use low pressure air. Keep the compressed air nozzle more than 30 cm away from the condenser to avoid damaging the of condenser fins.</li> <li>• Remove dust from inside the dryer, e.g. with a vacuum cleaner.</li> </ul> Do not use water or solvents to clean the condenser. Drive cleaning instructions: <ul style="list-style-type: none"> <li>• Clean NEOS Next heat sink with a vacuum cleaner.</li> </ul>

**Table 5: Additional checklist for compressors with dryer**

<sup>(1)</sup>More frequently when operating in a dusty atmosphere.



	<b>A-service every 4000 running hours<sup>(1)</sup></b>	<b>B-service every 8000 running hours<sup>(2)</sup></b>	<b>D-Service every 24000 running hours<sup>(3)</sup></b>
Check for water and oil leakages	x	x	x
Change the air filter	x	x	x
Check the prefilters	x	x	x
Change the drain(s) filter mesh	x	x	x
Change the oil	x <sup>(4)(7)</sup>	x <sup>(7)</sup>	x
Change the oil filter	x <sup>(4)(7)</sup>	x <sup>(7)</sup>	x
Change the oil separator element	x <sup>(8)</sup>	x	x
Overhaul non return valve of the scavenge line		x	x
Overhaul the minimum pressure valve		x	x
Overhaul the ER thermostatic valve		x <sup>(6)</sup>	x
Overhaul the condensate drain(s)		x	x
Change the motor top bearing			x
Inlet valve			x <sup>(5)</sup>
Smart Temperature Control (STC) valve			x

**Table 6: Preventive Maintenance schedule programmed in the controller**

<sup>(1)</sup>Or yearly (indicated by real time counter), whichever comes first.

<sup>(2)</sup>Or every 2 years (indicated by real time counter), whichever comes first.

<sup>(3)</sup>For compressor elements used on operating pressures below or equal to 10 bar (145 psi), the service can be postponed to 32000 running hours.

<sup>(4)</sup>When Roto Synthetic Fluid XTEND DUTY is used, the oil and oil filter change are part of the B-service in mild condititons.

<sup>(5)</sup>When the unit has over 300 000 start/stops (over 10 starts per hour) it's recommended to service the inlet valve and solenoid block.

<sup>(6)</sup>If the unit is equipped with optional energy recovery (ER).

<sup>(7)</sup>The oil change intervals are only applicable in mild conditions. In demanding or extreme conditions, the life of the oil can be reduced (see table below). Please contact your supplier to guarantee the life of your product in these conditions (supplier reference 9845 0141 01).

<sup>(8)</sup>Only for high pressure units the oil separator element has to be serviced at 4000h, this extra oil separator element is included in the 8000h kit.

## Oils

In order to achieve the best machine performance and guarantee the reliability, it is required to use genuine Atlas Copco lubricants. Their tailor made formulation is the result of years of field experience, research and in-house development. Consult the Spare Parts list for part number information.



**Danger:** Always consult your supplier if a timer setting has to be changed.

## 7.2 Oil specifications

See section *Preventive maintenance schedule* for the advised oil replacement intervals.



**Warning:** Avoid mixing lubricants of different brands or types as they may not be compatible and the oil mix may have inferior properties. A label, indicating the type of oil filled ex factory, is stuck on the air receiver/oil tank.



**Warning:** Only genuine Atlas Copco oils to be used.

Oil level to be checked on a daily basis.

Timely service of consumables is needed.

Use the correct personal protection equipment (gloves and safety goggles).

### Roto Synthetic Fluid ULTRA

Roto Synthetic Fluid ULTRA is a synthetic oil based lubricant, specially developed for use in single stage oil injected screw compressors running in demanding conditions. Roto Synthetic Fluid ULTRA can be used for compressors operating at ambient temperatures between 0 °C (32 °F) and 45 °C (113 °F). For more extreme conditions, or when longer oil life is required, it is recommended to use Roto Synthetic Fluid XTEND DUTY.

### Roto Synthetic Fluid XTEND DUTY

Atlas Copco's Roto Synthetic Fluid XTEND DUTY is a high quality synthetic lubricant for oil injected screw compressors which keeps the compressor in excellent condition. Because of its excellent oxidation stability, Roto Synthetic Fluid XTEND DUTY can be used for compressors operating at ambient temperatures between 0 °C (32 °F) and 46 °C (115 °F). Roto Synthetic Fluid XTEND DUTY is the standard lubricant for oil injected screw compressors equipped with freeze protection or Energy Recovery.

If the compressor is regularly operating in ambient temperatures above 40 °C (104 °F), oil lifetime is reduced. See sections *Preventive maintenance schedule* and *Oil, oil filter and oil separator change*.

### Roto Synthetic Foodgrade Ultra

#### Special oil, delivered as an option.

Atlas Copco's Roto Synthetic Foodgrade Ultra is a unique high quality synthetic lubricant, specially created for oil injected screw compressors that provide air for the food industry. This lubricant keeps the compressor in excellent condition. Roto Synthetic Foodgrade Ultra can be used for compressors operating at ambient temperatures between 0 °C (32 °F) and 46 °C (115 °F).

Roto Synthetic Foodgrade Ultra has all required certification for use in food & beverage industry: like NSFH1, Kosher, Halal and Allergen Free approvals.


If the compressor is regularly operating in ambient temperatures above 35 °C (95 °F), oil lifetime is reduced. See sections *Preventive maintenance schedule* and *Oil, oil filter and oil separator change*.

## 7.3 Drive motor

### Bearing maintenance

The motor bearing is lubricated by oil injection. Re-greasing is not necessary. See section *Preventive maintenance schedule* for bearing overhaul.

## 7.4 Air filter



### Procedure

1. Stop the compressor. Switch off the voltage.
2. Remove the cover of the air filter (AF) by opening the clip system. Remove the filter element.
3. Fit the new element and the cover.

## 7.5 Oil, oil filter and oil separator change



**Warning:** The operator must apply all relevant safety precautions.

Always drain the compressor oil at all drain points. Used oil left in the compressor can contaminate the oil system and can shorten the lifetime of the new oil.

Never mix lubricants of different brands or types as they may not be compatible and the oil mix will have inferior properties. A label, indicating the type of oil filled ex factory, is stuck on the air receiver/oil tank.

If the compressor is equipped with an Energy Recovery unit, also consult section *Maintenance for energy recovery systems*.



**Warning:** Only genuine Atlas Copco oils to be used.


Oil level to be checked on a daily basis.

Timely service of consumables is needed.

Use the correct personal protection equipment (gloves and safety goggles).

### Procedure

1. Run the compressor until warm and stop the compressor.
  - Close the air outlet valve.
  - Open the manual drain valve slowly.
  - Press the emergency stop button.
  - Wait 5 minutes for the compressor to depressurize the vessel.
  - Unscrew the oil filler plug (FC) just one turn to permit any remaining pressure in the system to escape.
2. Remove the vent plug (VP) of the oil cooler.



3. Open the oil drain valve (Do) and collect the oil in a collector.






Figure 32: Low pressure variant




**Figure 33: High pressure variant**

4. Completely drain the vessel.
5. Start the oil draining algorithm:
  - a. Log in as expert.
  - b. In the controller, go to **Test > Re-greasing / oil draining algorithm**.
  - c. Enter the security code.
  - d. Select **Activated**.
  - e. When activated, the blue light comes on:
    1. Blue light on:  
The algorithm is activated, the machine will run at 100 rpm for a pre-defined time (75s). It is safe to press start.
    2. Blue light off:  
The algorithm is not activated, the machine will start-up and regulate the speed according to air demand. It is not safe to press start.
  - f. Drain the vessel after running the algorithm.
6. If necessary, repeat the re-greasing / oil draining algorithm.
7. Clean the seat on the manifold. Lubricate the O-ring and metal lips of the new oil filter and screw it into place. Tighten firmly by hand.
8. Remove filler plug (FC).
9. Fill the air receiver with oil until the level reaches the filler neck.



**Figure 34: Low pressure variant**



**Figure 35: High pressure variant**

Take care that no dirt drops into the system. Refit and tighten filler plug (FC).

10. Run the compressor loaded for a few minutes.
11. Stop the compressor.
12. Close the air outlet valve and switch off the voltage.
  - Wait 3 minutes for the compressor to depressurize the vessel.
  - Open the condensate drain valve (Dm) to depressurize the cooler and close again. See section *Condensate system*.
  - Unscrew the oil filler plug (FC) just one turn to permit any remaining pressure in the system to escape.

13. Fill the air receiver (AR) with oil until the level reaches the filler neck. See section *During operation*.
14. Refit and tighten filler plug (FC).
15. When the oil level is too low, go back to step 13.


## 7.6 Coolers

### General

Keep the coolers clean to maintain their efficiency.

### Procedure

1. Stop the compressor, close the air outlet valve and switch off the voltage.
2. Cover all parts underneath the cooler.
3. Remove the service plate (1) at the fan compartment.



4. Remove dirt from the coolers with a fiber brush. Brush in the direction of the cooling fins.
5. Remove dirt from the fan with a fiber brush.
6. Clean with an air jet in the direction of the normal flow.
7. If it is necessary to wash the coolers with a cleaning agent, consult your supplier.



**Note:** After maintenance on the fan and on the coolers, remove the material that was used as cover.


8. Mount the service plate (1) at the fan compartment.

### Procedure for NEOS Next heat sink

1. Disassemble the fans at the bottom of the NEOS Next heat sink.
2. Remove dirt from the fans with a fiber brush.
3. If required, vacuum or blow through the heat sink with clean, dry air.
4. Remove dirt from the heat sink at the bottom with a fiber brush.
5. Reinstall the fans.
6. Check the fan functionality after re-installation.

### Procedure for compressors with dryer.

1. Remove dirt on the inlet of the condenser (6) with a fiber brush.



2. Clean with an air jet in the direction of the normal flow.
3. Clean the condenser area with a fiber brush.

## 7.7 Air dryer

### Safety precautions



**Danger:** Refrigeration dryers of ID type contain refrigerant HFC.

When handling refrigerant, all applicable safety precautions must be observed. Please be specifically aware of the following points:

- Contact of refrigerant with the skin will cause freezing. Special gloves must be worn. If contacted with the skin, the skin should be rinsed with water. On no account may clothing be removed.
- Fluid refrigerant will also cause freezing of the eyes; always wear safety glasses.
- Refrigerant is harmful. Do not inhale refrigerant vapors. Check that the working area is adequately ventilated.

Be aware that certain components such as the refrigerant compressor and the discharge pipe can become quite hot (up to 110 °C - 230 °F). Therefore, wait until the dryer has cooled down before removing the panels.

Before starting any maintenance or repair work, switch off the voltage and close the air inlet and outlet valves.

### Local legislation




**Warning:** Local legislation may stipulate that:

- Work on the refrigerant circuit of the cooling dryer or on any equipment which influences its function must be undertaken by an authorised control body.
- The installation should be checked once a year by an authorised control body.



## 7.8 RH sensor

### Cleaning



Reference	Description
RH	Relative humidity sensor

1. Remove the front service panel with the key delivered with the compressor.
2. Disconnect the RH sensor and remove it from the panel by loosening the bolt.
3. Clean the RH sensor with isopropanol (fast solution) or de-mineralised water and let it dry.
4. Refit and reconnect the RH sensor.
5. Refit the service panel.

## 7.9 Safety valves



**Danger:** No adjustments are allowed. Never run the compressor without safety valve.



Figure 36: Low pressure variant




Figure 37: High pressure variant

## Testing



**Warning:** The safety valve (SV) test can only be performed by authorized personnel and is protected by a security code.

If the safety valve does not open at the set pressure stamped on the valve, it needs to be replaced.

## 7.10 Filters

### DD, DD+ and UD+ filters

On DD, DD+ and UD+ filters, check at regular intervals that automatic drain valve is operative.

The filter elements of oil mist filters (DD, DD+ and UD+) should be replaced after 8000 hours. The gauge or pop-up is not a measure, as a typical oil mist filter operates in the steady state mode during its life and this mode is e.g. 200-250 mbar.

Note that the indicator or gauge will not move into the red area but will stay yellow or orange during operation.

Summarizing, the following service intervals should be observed (whatever comes first):

- 8000 operating hours
- 12 months in use
- Pressure drop: 350 mbar

## 7.11 Service kits

For overhauling and for preventive maintenance, a wide range of service kits is available. Service kits comprise all parts required for servicing the component and offer the benefits of genuine parts while keeping the maintenance budget low.

Also a full range of extensively tested lubricants, suitable for your specific needs is available to keep the compressor in excellent condition.


Consult the Spare Parts List for part numbers.

## 7.12 Drain replacement

### User access level


To replace the drain, you need to be in expert mode. This can be done as follows:

1. Tap the **Access Level** button (1) at the upper right corner of the screen.
2. Select the **Expert mode** (2).
3. Tap the confirm button (3).



87366


4. Type in the password to gain access.



87367

### Drain replacement

1. In the **CAN Troubleshooting** menu press **Make Inoperative** and confirm. Make sure that the compressor is off and in local control. In the inoperative state you will have new menu options to install or remove devices.




86421

2. Choose **Remove Device** and select the drain you want to replace in the drop-down menu. The data will be cleared from the configuration. Reboot the controller.



86422

3. To check if the drain has been removed correctly, you can navigate to the **IO modules** menu. The word **Removed** should be displayed now.



86423

4. Navigate to **Install Device**. The drain you just removed should now be available in the list. Select it and confirm the installation.

Confirm and restart the controller from the **CAN Troubleshooting** menu.

5. Verify drain communication in the **CAN Troubleshooting > IO modules** menu.
6. Restart the controller from the **CAN Troubleshooting** menu.

The easiest way to replace a drain is through the **CAN Troubleshooting** menu. Replacing drains should be done one by one. Removing multiple devices at the same time is not recommended.

## 8 Problem solving



**Warning:** Before carrying out any maintenance, repair work or adjustment, stop the compressor, wait 3 minutes and close the air outlet valve.

Press the emergency stop button and switch off the voltage. Lock Out Tag Out (LOTO) the electrical supply.

Press the test button on top of the electronic water drain until the air system between the air receiver and outlet valve is fully depressurized.

Depressurize the compressor by opening the oil filler plug one turn.

For the location of components, see sections:

- *Introduction*
- *Condensate system*
- *Operating instructions*
- *Maintenance*

Open and lock the isolating switch.

Lock the air outlet valve during maintenance or repair as follows:

- Close the valve.
- Remove the screw fixing the handle with the wrench delivered with the compressor.
- Lift the handle and turn it until the slot of the handle fits over the blocking edge on the valve body.
- Fit the screw.



**Warning:** The operator must apply all relevant safety precautions.



**Warning:** Wait for at least 10 minutes before starting any electrical repairs as dangerous high voltage remains on the capacitors of the start and speed regulation unit for some minutes after switching off the voltage.

### Faults and remedies, compressor

Condition	Fault	Remedy
Condensate is not discharged from condensate separator during loading	Discharge flexible clogged	Check and correct as necessary.

Condition	Fault	Remedy
Compressor air output or pressure below normal	Air consumption exceeds air delivery of compressor	Check equipment connected.
	Choked air filter element	Replace filter element.
	Solenoid valve malfunctioning	Replace valve.
	Oil separator clogged	Have element replaced.
	Air leakage	Have leaks repaired.
	Safety valve leaking	Have valve replaced.
	Compressor element out of order	Consult Atlas Copco.

Condition	Fault	Remedy
Safety valve blows	Minimum pressure valve malfunctioning	Check and have defective parts replaced.
	Oil separator clogged	Have element replaced.
	Safety valve out of order	Have valve checked. Replace if necessary.
	On Full-Feature compressors, dryer piping clogged due to formation of ice	Have system checked by your supplier.

Condition	Fault	Remedy
Compressor element outlet temperature or delivery air temperature above normal	Oil level too low	Check and correct, see section <i>During operation</i> .
	On air-cooled compressors, insufficient cooling air or cooling air temperature or relative humidity is too high	Check for cooling air restriction or improve ventilation of the compressor room. Avoid recirculating of cooling air. If installed, check capacity of compressor room fan.
	Oil cooler clogged	Clean cooler.
	By-pass valve malfunctioning	Have valve tested.
	Air cooler clogged	Clean cooler.
	Compressor element out of order	Consult your supplier.
	Degraded oil	Check service intervals, see section <i>Preventive maintenance schedule</i> .
	On compressors with optional energy recovery system, cooling water flow too low.	Increase flow.
	On compressors with optional energy recovery system, restriction in cooling water system.	Consult your supplier.

Condition	Fault	Remedy
Low Load Alarm triggered: Compressor running with too low oil temperature over a longer period of time	Solenoid valve malfunctioning	Replace valve.
	Extreme low usage of compressor	Increase loading profile (longer and/or more load cycles required). If not possible, consult your supplier.

**Faults and remedies, NEOS converter**

Controller alarm code (Decimal)	NEOS browser alarm code (Hexadecimal)	Fault description	Detailed description	Actions
	<b>0x2000</b>			
8978	0x2312	Main Motor overcurrent	Overcurrent detected at motor side.	Check motor, oil, valves and element. If the error returns, contact your supplier.
8979	0x2313	Main Motor overcurrent	High common mode current detected.	Check for shortcircuits or line-to-ground faults in the motor, motor cables and/or connections.
8980	0x2314	Main Motor overcurrent	Overcurrent detected at motor side.	Check motor, oil, valves and element. If the error returns, contact your supplier.
8981	0x2315	Main Motor overcurrent	Short circuit detected in U phase.	Try to reset the error. If the error returns, contact your supplier.
8982	0x2316	Main Motor overcurrent	Short circuit detected in V phase.	
8983	0x2317	Main Motor overcurrent	Short circuit detected in W phase.	
8992	0x2320	Fan Motor overcurrent	Overcurrent detected at motor side.	Check fan motor and coolers. If the error returns, contact your supplier.
8993	0x2321			
	<b>0x3000</b>			

Controller alarm code (Decimal)	NEOS browser alarm code (Hexadecimal)	Fault description	Detailed description	Actions
12816	0x3210	Overvoltage	Overvoltage on DC bus detected.	Check if the main supply is within specifications. Check for transient voltage phenomena (e.g. voltage dips, surges, etc.). Check main fuses.
12817	0x3211	Overvoltage		
12833	0x3221	Undervoltage		
12834	0x3222	Undervoltage	Undervoltage on DC bus detected.	
	<b>0x4000</b>			
16385	0x4001	Drive overtemperature	Pt1000 Temperature measurements exceed 130°C.	Check which temperature measurement is too high in the controller.
16913	0x4211	Drive overtemperature	Overtemperature detected in fan inverter IGBT.	Let the drive cool off. Check for excessive ambient temperature. Clean heat sink with compressed air. Clean inlet filter cubicle. Ensure proper flow of cooling air in compressor room.
16914	0x4212	Drive overtemperature	Overtemperature detected in control board microcontroller.	
16915	0x4213	Drive overtemperature	Overtemperature detected in bridge board microcontroller.	



Controller alarm code (Decimal)	NEOS browser alarm code (Hexadecimal)	Fault description	Detailed description	Actions
17169	0x4311	Drive overtemperature	Overtemperature detected in main inverter IGBT.	Check for overloads. Let the drive cool off. Check for excessive ambient temperature. Clean the heat sink with compressed air. Clean the inlet filter of the cubicle. Ensure proper flow of cooling air in the compressor room.
17172	0x4314	Drive overtemperature	Overtemperature detected in IGBT junction UH (thermal model).	
17173	0x4315	Drive overtemperature	Overtemperature detected in IGBT junction UL (thermal model).	
17174	0x4316	Drive overtemperature	Overtemperature detected in IGBT junction VH (thermal model).	
17175	0x4317	Drive overtemperature	Overtemperature detected in IGBT junction VL (thermal model).	
17176	0x4318	Drive overtemperature	Overtemperature detected in IGBT junction WH (thermal model).	
17177	0x4319	Drive overtemperature	Overtemperature detected in IGBT junction WL (thermal model).	
17184	0x4320	Drive overtemperature	Overtemperature detected on powerboard PCB.	Let the drive cool off. Check for excessive ambient temperature. Clean the heat sink with compressed air. Clean the inlet filter of the cubicle. Ensure proper flow of cooling air in the compressor room.
17185	0x4321	Drive overtemperature	Overtemperature detected on control board PCB.	
17200	0x4330	Drive overtemperature	Overtemperature detected on bridge board PCB.	
17201	0x4331	Drive overtemperature	Overtemperature detected on PSU board PCB.	
17204	0x4334	Drive overtemperature	Overtemperature detected in rectifier.	

Controller alarm code (Decimal)	NEOS browser alarm code (Hexadecimal)	Fault description	Detailed description	Actions
17206	0x4336	Drive overtemperature	Overtemperature detected by simplified thermal model.	Check for overloads. Let the drive cool off. Check for excessive ambient temperature. Clean the heat sink with compressed air. Clean the inlet filter of the cubicle. Ensure proper flow of cooling air in the compressor room.
17207	0x4337	Drive overtemperature	Overtemperature detected in main IGBT.	Let the drive cool off. Check for excessive ambient temperature. Clean the heat sink with compressed air. Clean the inlet filter of the cubicle. Ensure proper flow of cooling air in the compressor room.
17208	0x4338	Drive overtemperature	Overtemperature detected in AC choke.	
17209	0x4339	Drive overtemperature	Overtemperature detected in fan IGBT.	
17219	0x4343	Drive overtemperature	Overtemperature detected in rectifier.	
17220	0x4344	Drive overtemperature	Main motor overload.	Check for overloads.
	<b>0x5000</b>			
20512	0x5020	Emergency off (STO)	Emergency stop circuit opened.	Check the emergency stop button. Check for loose connectors at the control unit of the converter.
20513	0x5021	Emergency off (STO)		

Controller alarm code (Decimal)	NEOS browser alarm code (Hexadecimal)	Fault description	Detailed description	Actions
20756	0x5114	Drive failure (hardware)	Internal power supply tripped.	Check if the main supply is within specifications. Check for transient voltage phenomena (e.g. voltage dips, surges, etc.). Check main fuses.
21505	0x5401	Drive failure (hardware)	General fault detected in power section.	Try to reset the error. If the error returns, contact your supplier.
21507	0x5403	Drive failure (hardware)		
21508	0x5404	Drive failure (hardware)	Internal power supply tripped.	Check if the main supply is within specifications. Check for transient voltage phenomena (e.g. voltage dips, surges, etc.). Check main fuses.
<b>0x6000</b>				
24832	0x6100	Drive failure (hardware)	General software fault, conditions not respected inside the CB app FW code.	Reboot the system or turn off the unit and then turn it on again. If the error returns, contact your supplier.
24834	0x6102	Drive failure (hardware)	Failed temperature reading of power board. Time-out communication at initialization.	Try to reset the error. If the error returns, contact your supplier.
24840	0x6108	Drive failure (hardware)	Internal communication timeout.	
24846	0x610E	Drive failure (hardware)	Not able to identify power board.	

<b>Controller alarm code (Decimal)</b>	<b>NEOS browser alarm code (Hexadecimal)</b>	<b>Fault description</b>	<b>Detailed description</b>	<b>Actions</b>
24851	0x6113	Drive failure (software)	CAN communication overload.	Check the CAN-cable connection between the controller and the converter. Check the position of the CAN termination switch at both sides of the CAN cable. Both should be OFF.
24853	0x6115	Drive failure (software)	Foreground part 2 runs out of time (not concluded before the next foreground part 1 update event).	Try to reset the error. If the error returns, contact your supplier.

Controller alarm code (Decimal)	NEOS browser alarm code (Hexadecimal)	Fault description	Detailed description	Actions
24854	0x6116	Drive failure (software)	BB MCU did not jump into bootloader state during the initialization phase.	Reboot the system or turn off the unit and then turn it on again. If the error returns, contact your supplier.
24855	0x6117	Drive failure (software)	BB MCU did not jump into application state during the initialization phase.	
24856	0x6118	Drive failure (software)	Timeout, CB MCU not able to read the BB Boot firmware version.	
24857	0x6119	Drive failure (software)	Timeout, CB MCU not able to read the BB App firmware version.	
24858	0x611A	Drive failure (software)	Serializer 24 V for read/write of CB I/O's not properly configured.	
24859	0x611B	Drive failure (software)	BB hardware revision is not recognized by CB MCU.	
24860	0x611C	Drive failure (software)	PB hardware revision is not recognized by CB MCU.	
24861	0x611D	Not used	Not used	Not used

Controller alarm code (Decimal)	NEOS browser alarm code (Hexadecimal)	Fault description	Detailed description	Actions
24862	0x611E	Drive failure (software)	CB hardware revision is not recognized by CB MCU.	Reboot the system or turn off the unit and then turn it on again. If the error returns, contact your supplier.
24863	0x611F	Drive failure (software)	BB FW Boot version is not recognized by CB MCU.	
24864	0x6120	Drive failure (software)	BB FW App version is not recognized by CB MCU.	
24865	0x6121	Drive failure (software)	CB FW Boot version is not recognized by CB MCU.	
24866	0x6122	Drive failure (software)	CAN communication fault.	Check the CAN-cable connection between the controller and the converter. Check the position of the CAN termination switch at both sides of the CAN cable. Both should be OFF.
24867	0x6123	Drive failure (software)	V/F profile not correct.	Redownload the parameters to Neos. If the error returns, contact your supplier.
24868	0x6124	Drive failure (software)	Error in read/write from/into BB EEPROM.	Reboot the system or turn off the unit and then turn it on again. If the error returns, contact your supplier.
24869	0x6125	Drive failure (software)	Error in read/write from/into CB EEPROM.	
24870	0x6126	Drive failure (software)	No reliable values obtained during inductance identification procedure.	Reset the error and repeat the procedure. If the error returns, contact your supplier.

Controller alarm code (Decimal)	NEOS browser alarm code (Hexadecimal)	Fault description	Detailed description	Actions
24873	0x6129	Drive failure (software)	First ADC regular acquisition sequence not executed in time.	Try to reset the error. If the error returns, contact your supplier.
24874	0x612A	Drive failure (software)	Foreground part 1 not executed.	
24875	0x612B	Drive failure (software)	Voltage saturation during the inductance identification procedure (more Vbus needed to conclude the procedure).	Reset the error and repeat the procedure. If the error returns, contact your supplier.
24876	0x612C	Drive failure (software)	No reliable values obtained by the ADC's during the Vbus oversampling.	Try to reset the error. If the error returns, contact your supplier.
24877	0x612D	Drive failure (software)	Error in read diagnostic from BB EEPROM.	Reboot the system or turn off the unit and then turn it on again. If the error returns, contact your supplier.
24878	0x612E	Drive failure (software)	Failure at initial position detection.	Reset and try again. If the problem still persists, try to reduce the vessel pressure. If the error returns, contact your supplier.
24879	0x612F	Drive failure (software)	Foreground part 1 runs out of time (not concluded before the next foreground part 2 update event).	Try to reset the error. If the error returns, contact your supplier.
24880	0x6130	Drive failure (software)	Induction motor not magnetized.	

Controller alarm code (Decimal)	NEOS browser alarm code (Hexadecimal)	Fault description	Detailed description	Actions
24885	0x6135	Drive failure (software)	Negative value obtained for the rotor time during IM parameters identification procedure.	Reset the error and repeat the procedure. If the error returns, contact your supplier.
24886	0x6136	Drive failure (software)	The identification procedure was not completed within the time limit (5 minutes).	
24887	0x6137	Drive failure (software)	The reference current (P431) used for the identification procedure is not big enough.	
24888	0x6138	Drive failure (software)	Foreground runs out of time (not concluded before the next foreground interrupt update event).	Try to reset the error. If the error returns, contact your supplier.
	<b>0x7000</b>			
28976	0x7130	Main Motor overtemperature	Motor overtemperature detected.	Let the motor cool off. Ensure that the main fan and the air flow in and out of the compressor is not obstructed. Ensure proper flow of cool air in the compressor room. Check for loose connectors at the control unit of the converter.
	<b>0x8000</b>			



Controller alarm code (Decimal)	NEOS browser alarm code (Hexadecimal)	Fault description	Detailed description	Actions
33025	0x8101	Drive failure (software)	CAN communication fault.	Check the CAN-cable connection between the controller and the converter. Check the position of the CAN termination switch at both sides of the CAN cable. Both should be OFF.
33041	0x8111	Drive failure (software)		
33042	0x8112	Drive failure (software)		
33057	0x8121	Drive failure (software)		
33058	0x8122	Drive failure (software)		
33073	0x8131	Drive failure (software)		
33089	0x8141	Drive failure (software)		
33793	0x8401	Drive failure (software)	Motor maximum speed exceeded.	Try to reset the error. If the error returns, contact your supplier.
33794	0x8402	Drive failure (software)	Motor stalled.	Check for blockages.
33795	0x8403	Negative speed	Electrical connection incorrect. Wrong rotation direction of the main motor.	Try again after reducing the pressure in the vessel. Swap two power cables.
	<b>0x9000</b>			
36866	0x9002	Hardware run enable missing	Hardware enable signal for fan inverter missing.	Reset and try again.
	<b>0xA000</b>			
40976	0xA010	Overload on digital outputs	Overload on digital outputs.	Check the wiring and connected devices to 24 VDC AUX PSU.
40977	0xA011	Overload on digital outputs		
40978	0xA012	Overload on digital outputs		Check the wiring and connected devices to 24 VDC digital outputs.
40979	0xA013	Overload on digital outputs		
	<b>0xB000</b>			
45056	0xB000	I/O disabled	Emergency stop circuit opened or "ALL_DEVICES" fault occurred.	Check the emergency stop button. Reset and try again.

**Faults and remedies, dryer**

For all references hereafter, consult section *Air dryer*.

Condition	Fault	Remedy
Pressure dew point too high	Air inlet temperature too high	Check and correct; if necessary, clean the aftercooler of the compressor.
	Ambient temperature too high	Check and correct; if necessary, draw cooling air via a duct from a cooler place or relocate the compressor.
	Shortage of refrigerant	Have circuit checked for leaks and recharged.
	Refrigerant compressor does not run	See below.
	Evaporator pressure too high	See below.
	Condenser pressure too high	See below.
Condenser pressure too high or too low	Fan control switch out of order	Replace.
	Fan blades or fan motor out of order	Have checked fan/fan motor, if necessary replace.
	Ambient temperature too high	Check and correct; if necessary, draw cooling air via a duct from a cooler place or relocate the compressor.
	Condenser externally clogged	Clean condenser.
Compressor stops or does not start	Electric power supply to compressor is interrupted	Check and correct as necessary.
	Thermal protection of refrigerant compressor motor has tripped	Motor will restart when motor windings have cooled down.
Electronic condensate drain remains inoperative	Electronic drain system clogged	Have system inspected. Clean the filter of the automatic drain by opening the manual drain valve. Check functioning of the drain by pushing the test button.
Condensate trap continuously discharges air and water	Automatic drain out of order	Have system checked. If necessary, replace the automatic drain.
Evaporator pressure is too high or too low at unload	Hot gas bypass valve incorrectly set or out of order	Have hot gas bypass valve adjusted.
	Condenser pressure too high or too low	See above.
	Shortage of refrigerant	Have circuit checked for leaks and recharged if necessary.

Condition	Fault	Remedy
No compressed air passes through the dryer outlet	The pipes are frozen inside	The bypass valve is broken or out of calibration.
		The room temperature is too low and the evaporator piping is obstructed with ice.
Presence of condensate in pipings	The condensate separator does not work properly	Clean the filter from the condensate drain.
		Check the condensate drain.

## 9 Technical data

### 9.1 Readings on display



85199D

Figure 38: Elektronikon™ Touch controller



**Note:** The data is valid under the reference conditions. See section *Reference conditions and limitations*.

Reference	Reading
Air outlet pressure	Depends on the setpoint (desired net pressure).
Compressor element outlet temperature	Approx. 80 °C (176 °F) (ambient temperature 20 °C + 60 °C)
Dewpoint temperature (on units with integrated dryer)	Approx. 4 °C (39 °F).

### 9.2 Electric cable size and fuses



**Warning:** We only refer to existing norms or calculation methods but don't take any responsibility about them or the completeness of information, this is the responsibility of the customer. Failing to supply correct power or protection can void the warranty.

The voltage on the compressor terminals must not deviate more than 10% of the nominal voltage. It is however highly recommended to keep the voltage drop over the supply cables at nominal current below 5% of the nominal voltage (IEC 60204-1).

If cables are grouped together with other power cables, it may be necessary to use cables of a larger size than those calculated for the standard operating conditions.

Use the original cable entry. See section *Dimension drawings*.

To preserve the IP protection degree of the electrical cubicle and to protect its components from dust from the environment, it is mandatory to use a proper cable gland when connecting the supply cable to the compressor.

Local regulations remain applicable if they are stricter than the values proposed below.

Always double-check the fuse size versus the calculated cable size. If required, reduce fuse size or enlarge cable size.

Cable length should not exceed the maximum length according to IEC60204 table 10.



**Note:** The correct torque has to be applied on the supply cables.

**Leakage breaker (optional)**

If the installation requires a leakage breaker, always use an all current sensitive leakage breaker, RCM or RCD Type B (according to IEC/EN 60755) with a sufficient trip level.

**Currents and fuses**

Type			$I_{max}^{(1)}$	Max fuse <sup>(1)</sup>		$I_{max}^{(2)}$	Max fuse <sup>(2)</sup>	
				aR	gL/gG		aR	gL/gG
	V	Hz	A	A	A	A	A	A
GA 5 VSD <sup>s</sup>	200	50/60	36		40	42		40
	230	50/60	32		32	37		40
	380	60	19	20		25	25	
	400	50	18	20		24	25	
	460	60	16	16		21	20	
	500	50	15		16	18		20

**Table 7: IEC approval**

Type			$I_{max}^{(1)}$	Max fuse <sup>(1)</sup>		$I_{max}^{(2)}$	Max fuse <sup>(2)</sup>	
				aR	gL/gG		aR	gL/gG
	V	Hz	A	A	A	A	A	A
GA 7 VSD <sup>s</sup>	200	50/60	36		40	42		40
	230	50/60	32		32	37		40
	380	60	19	20		25	25	
	400	50	18	20		24	25	
	460	60	16	16		21	20	
	500	50	15		16	18		20

**Table 8: IEC approval**

Type			$I_{max}^{(1)}$	Max fuse <sup>(1)</sup>		$I_{max}^{(2)}$	Max fuse <sup>(2)</sup>	
				aR	gL/gG		aR	gL/gG
	V	Hz	A	A	A	A	A	A
GA 11 VSD <sup>s</sup>	200	50/60	56		63	62		63
	230	50/60	49		50	55		63
	380	60	30	32		35	35	
	400	50	28	32		34	35	
	460	60	25	25		30	32	
	500	50	23		25	28		32

Table 9: IEC approval

Type			$I_{max}^{(1)}$	Max fuse <sup>(1)</sup>		$I_{max}^{(2)}$	Max fuse <sup>(2)</sup>	
				aR	gL/gG		aR	gL/gG
	V	Hz	A	A	A	A	A	A
GA 15 VSD <sup>s</sup>	200	50/60	76		80	84		80
	230	50/60	67		80	74		80
	380	60	40	40		48	50	
	400	50	38	40		46	50	
	460	60	33	35		41	40	
	500	50	31		32	38		40

Table 10: IEC approval

Type			$I_{max}^{(1)}$	Max fuse <sup>(1)</sup>		$I_{max}^{(2)}$	Max fuse <sup>(2)</sup>	
				aR	gL/gG		aR	gL/gG
	V	Hz	A	A	A	A	A	A
GA 18 VSD <sup>s</sup>	200	50/60	90		100	99		100
	230	50/60	80		80	87		100
	380	60	48	50		56	63	
	400	50	46	50		53	50	
	460	60	40	40		47	50	
	500	50	37		40	44		50

Table 11: IEC approval

Type			$I_{max}^{(1)}$	Max fuse <sup>(1)</sup>		$I_{max}^{(2)}$	Max fuse <sup>(2)</sup>	
				Class T	Class J		Class T	Class J
	V	Hz	A	A	A	A	A	A
GA 5 VSD <sup>s</sup>	200	50/60	36		35	42		45
	230	50/60	32		35	37		40
	575	60	13		15	18		20
	460	60	16	15		21	20	

Table 12: UL/cUL approval

Type			$I_{max}^{(1)}$	Max fuse <sup>(1)</sup>		$I_{max}^{(2)}$	Max fuse <sup>(2)</sup>	
				Class T	Class J		Class T	Class J
	V	Hz	A	A	A	A	A	A
GA 7 VSD <sup>s</sup>	200	50/60	36		35	42		45
	230	50/60	32		35	37		40
	575	60	13		15	18		20
	460	60	16	15		21	20	

**Table 13: UL/cUL approval**

Type			$I_{max}^{(1)}$	Max fuse <sup>(1)</sup>		$I_{max}^{(2)}$	Max fuse <sup>(2)</sup>	
				Class T	Class J		Class T	Class J
	V	Hz	A	A	A	A	A	A
GA 11 VSD <sup>s</sup>	200	50/60	56		60	62		60
	230	50/60	49		50	55		60
	575	60	20		20	25		25
	460	60	25	25		30	30	

**Table 14: UL/cUL approval**

Type			$I_{max}^{(1)}$	Max fuse <sup>(1)</sup>		$I_{max}^{(2)}$	Max fuse <sup>(2)</sup>	
				Class T	Class J		Class T	Class J
	V	Hz	A	A	A	A	A	A
GA 15 VSD <sup>s</sup>	200	50/60	76		80	84		90
	230	50/60	67		70	74		80
	575	60	27		30	34		35
	460	60	33	35		41	40	

**Table 15: UL/cUL approval**

Type			$I_{max}^{(1)}$	Max fuse <sup>(1)</sup>		$I_{max}^{(2)}$	Max fuse <sup>(2)</sup>	
				Class T	Class J		Class T	Class J
	V	Hz	A	A	A	A	A	A
GA 18 VSD <sup>s</sup>	200	50/60	92		90	99		100
	230	50/60	80		80	87		90
	575	60	32		35	39		40
	460	60	40	40		47	50	

**Table 16: UL/cUL approval**

$I_{max}$ : Current in the supply lines at maximum load and 10% undervoltage.

(1)Compressors without integrated dryer.

(2)Compressors with integrated dryer.

## Earthing

The earthing cable connected to the compressor (PE) should be minimum 10 mm<sup>2</sup> (according to EN 60204-1 section 828).

## Motor cables

Model	Cable assembly number	Size	Quantity	Wire ends
GA 5 VSD <sup>s</sup>	1649 8102 34	6	1	M8
GA 7 VSD <sup>s</sup>	1649 8102 34	6	1	M8
GA 11 VSD <sup>s</sup>	1649 8102 34	6	1	M8
GA 15 VSD <sup>s</sup>	1649 8102 34	6	1	M8
GA 18 VSD <sup>s</sup>	1649 8102 35	10	1	M8


## Cable sizing according IEC

The tables below indicate the current carrying capacities of cables for 3 commonly used installation methods, calculated according to standard 60364-5-52 - electrical installations of buildings part 5 - selection and erection equipment and section 52 - current carrying capacities in wiring systems.

The allowed currents are valid for XLPE cables with three loaded copper conductors.

Cable section	Ambient temperature				
	30 °C	40 °C	45 °C	50 °C	55 °C
4 mm <sup>2</sup>	< 27 A	< 23 A	< 21 A	< 19 A	< 16 A
6 mm <sup>2</sup>	< 34 A	< 30 A	< 27 A	< 24 A	< 21 A
10 mm <sup>2</sup>	< 46 A	< 40 A	< 36 A	< 33 A	< 28 A
16 mm <sup>2</sup>	< 62 A	< 54 A	< 49 A	< 44 A	< 38 A
25 mm <sup>2</sup>	< 80 A	< 70 A	< 63 A	< 57 A	< 49 A
35 mm <sup>2</sup>	< 99 A	< 86 A	< 78 A	< 70 A	< 60 A
50 mm <sup>2</sup>	< 118 A	< 103 A	< 93 A	< 84 A	< 72 A
70 mm <sup>2</sup>	< 149 A	< 130 A	< 118 A	< 106 A	< 91 A
95 mm <sup>2</sup>	< 179 A	< 156 A	< 141 A	< 127 A	< 109 A
120 mm <sup>2</sup>	< 206 A	< 179 A	< 163 A	< 146 A	< 126 A

**Table 17: Maximum allowed current in function of the ambient temperature for installation method B2**

	Installation method B2 according table B.52.1. Multi-core cable in conduit on a wooden wall.
---	---

### Calculation method for IEC:

- Single supply cables (3 phases + PE - configuration (1)):
  - Add 10 % to the total compressor current ( $I_{tot}^{Pack}$  or  $I_{tot}^{FF}$  from the tables)
  - Install the prescribed fuse on each cable
- Parallel supply cable (2 x 3 phases + PE - configuration (2)):
  - Add 10 % to the total compressor current ( $I_{tot}^{Pack}$  or  $I_{tot}^{FF}$  from the tables) and divide by 2



- Multiply the ampacity of the cables with 0.8 (see table A.52.17 (52-E1))
- Install fuses of half the size of the recommended maximum fuse size on each cable.
- Size of the PE cable:
  - For supply cables up to 35 mm<sup>2</sup>: same size as supply cables
  - For supply cables larger than 35 mm<sup>2</sup>: half the size of the supply wires

Always check the voltage drop over the cable (less than 5 % of the nominal voltage is recommended).

**Example 1:**  $I_{\text{tot}} = 178 \text{ A}$ , maximum ambient temperature is 45 °C, recommended fuse = 200 A

- Single supply cables (3 phases + PE - configuration (1)):
- $I = 178 \text{ A} + 10 \% = 178 \times 1.1 = 196 \text{ A}$
- The table for method F 70° C conductor and ambient temperature = 45°C allows a maximum current of 209 A for a 95mm<sup>2</sup> cable.

Therefore, use a 3 x 95 mm<sup>2</sup> + 50 mm<sup>2</sup> cable.

If method F 90°C conductor is used, 70 mm<sup>2</sup> is sufficient.

Therefore 3 x 50 mm<sup>2</sup> + 25mm<sup>2</sup> can be used.

**Example 2:**  $I_{\text{tot}} = 178 \text{ A}$ , 424 A, maximum ambient temperature is 45 °C, recommended fuse = 500 A

#### With transformer

- Single supply cables with a maximum section of 150mm<sup>2</sup> (3 phases + PE – configuration (1)):
  - $I = 424 \text{ A} + 10 \% = 424 \times 1.1 = 466 \text{ A}$
  - The table for method F 90° C conductor and ambient temperature = 45 ° C allows a maximum current of 386 A for a 150mm<sup>2</sup> cable.
  - 150mm<sup>2</sup> is the maximum cable size that can be connected. So we need to use configuration (2)
- Parallel supply cable (2 x 3 phases + PE - configuration (2)):
  - $I = (424 \text{ A} + 10 \%)/2 = (424 \times 1.1)/2 = 233 \text{ A}$
  - For a cable of 120 mm<sup>2</sup>, method F 90°C conductor at 45 °C, the maximum current is 333 A x 0.8 = 266 A. So 2 parallel cables of 3 x 120 mm<sup>2</sup> + 70 mm<sup>2</sup> are sufficient.
  - Install 250 A fuses on each cable.

#### Cable sizing according UL/cUL

Calculation method according UL 508A, table 28.1 column 5: allowable ampacities of insulated copper conductors (75 °C (167 °F)).

If multi-core 1 AWG cable is to be used, the part on the inside of the unit should be stripped and cable tied to the frame of the unit.



Make sure to mount the pyramid gland after connecting the supply cable to safeguard the IP rating of the converter.

AWG or kcmil	Maximum current
10	< 30 A
8	< 50 A
6	< 65 A
4	< 85 A
3	< 100 A
2	< 115 A
1	< 130 A
1/0	< 150 A
2/0	< 175 A
3/0	< 200 A

**Table 18: Maximum allowed current in function of the wire size**

**Calculation method for UL:**

- Single supply cables (3 phases + 1 PE - configuration (1)):
  - Add 25 % to the total current from the tables (see UL 508A 28.3.2: "Ampacity shall have 125 % of the full load current")
  - Install the prescribed maximum fuse on each cable
- Parallel supply cable (2 x 3 phases + 2 PE - configuration (2)):
  - Add 25 % to the total current from the tables and divide by 2
  - Multiply the ampacity of the cables with 0.8 (see UL 508A table 28.1 continued)
  - Install fuses of half the size of the recommended maximum fuse size on each cable.
- When using 2 x 3 phase + 2 PE as in (3):
  - Add 25 % to the total current from the tables and divide by  $\sqrt{3}$
  - Multiply the ampacity of the cables with 0.8 (see UL 508A table 28.1 continued)
  - Fuse size: the recommended maximum fuse size divided by  $\sqrt{3}$  on each cable.
- Size PE cable:
  - For supply cables up to AWG8: same size as the supply cables

- For supply cables larger than AWG8: use maximum allowed ampacity of the selected supply cables and compare with value in table below (see CEC Part 1 table 17)

< 100 A: use AWG8
< 200 A: use AWG6
< 300 A: use AWG4

Always check the voltage drop over the cable (less than 5 % of the nominal voltage is recommended).

**Example 3:**  $I_{tot} = 189$  A, maximum ambient temperature is 45 °C, recommended fuse = 225 A

- Single supply cables(3 phases + PE – configuration (1)):
  - $I = 189 \text{ A} + 25 \% = 189 \times 1.25 = 207 \text{ A}$
  - For AWG 4/0, the maximum current is 230A, which is sufficient.
  - Install the prescribed maximum fuse 225A on each cable.

**Cable sizing according CSA**

Most commonly installation will be done according CEC part1 (C22.1-09): “Canadian Electrical Code, Part I Safety Standard for Electrical Installations”, but local electrical codes will prevail at the site that the equipment is installed.

Installation information on calculating minimum required ampacity for the conductors:

- According to local electrical codes which will generally require that the cable must be sized to provide at least 125% of the complete package amps.
- Use  $I_{tot}$  FF or  $I_{tot}$  pack and multiply with 125%

**Calculation method for CSA**

According to CEC part1 (C22.1-09): Multiply the FLA of the main motor with 125% and add the sum of the FLA’s of all other motors and the additional loads.

Note that CEC part1 (C22.1-09) states that the 125% is minimum for motors with a 1.15 service factor, this is 10% above the service factor of the motor. For SF equal or less than 1.15, multiply FLA by 125%. For SF greater than 1.15, use actual service factor + 10% to calculate the minimum amperage requirement.

To determine the additional load, we subtract from  $I_{tot}$ , the main motor  $FLA \times SF$ .

**Examples**

Compressor Type: Full feature with  $I_{tot}$  FF = 125A

- Additional load part of this =  $125 - (91 \times 1.2) = 125 - 109.2 = 15.8A$
- FLA (Full Load Amps) main motor = 91A
- SF (Service Factor) main motor = 1.20
- Maximum operating ambient temperature is 50°C

In these examples we will use cables as described in CEC part1 (C22.1-09), Table 2 col.3.

Correction factor for other ambient temperature can be found in CEC part1 (C22.1-09), Table 5A.

For this example, this will be 0.75.

Correction factor for more than 3 current carrying cables can be found in CEC part1 (C22.1-09), Table 5C: for the use of 6 cables this will be 0.80.

SF is more than 1.15, so multiply FLA with SF+10% i.e., FLA \*130%.

**Single supply cables (3phases + 1PE – configuration (1)):**

- According to CEC part1 (C22.1-09) we will need a cable suitable for:
  - Multiply FLA of the main motor with 120% +10% = 130%,  
 $91 * 130\% = 118.3A$   
 Add the additional loads  
 $I_{cable} = 118.3 + 15.8 = 134.1A$
  - Cable AWG 2/0 is not suitable:  
 Allowed amps on ambient 50°C =  $175 * 0.75 = 131.25A$   
 $131.25A < 134.1A$ , this cable section is too small.
  - At least cable AWG 3/0 must be used:  
 Allowed amps on ambient 50°C =  $200 * 0.75 = 150A$   
 $150A > 134.1A$ , this cable section is ok.

**Parallel supply cables (2 x 3phase + 1PE – configuration (2)):**

- According to CEC part1 (C22.1-09) we will need a cable suitable for:
  - Multiplied FLA of the main motor with 120% +10% = 130%,  
 $91 * 130\% = 118.3A$
  - Add the additional loads  
 $I_{cable} = 118.3 + 15.8 = 134.1A$
  - Divide by 2 for the use of 6 cables as in fig 2  
 $134.1 / 2 = 67A$
  - Cable AWG 3 is not suitable:  
 Allowed amps on ambient 50°C =  $100 * 0.75 = 75A$   
 Correction for 6 cables =  $75 * 0.8 = 60A$   
 $60A < 67A$ , this cable section is too small
  - At least cable AWG 2 must be used  
 Allowed amps on ambient 50°C =  $115 * 0.75 = 86.25A$   
 Correction for 6 cables =  $86.25 * 0.8 = 69A$   
 $69A > 67A$ , this cable section is ok

**9.3 Reference conditions and limitations**

**Reference conditions**

Air inlet pressure (absolute)	bar	1
Air inlet pressure (absolute)	psi	14.5
Air inlet temperature	°C	20
Air inlet temperature	°F	68

Relative humidity	%	0
Working pressure		See section <i>Compressor data</i> .

### Limitations

Maximum working pressure		See section <i>Compressor data</i> .
Minimum working pressure	bar(e)	4
Minimum working pressure	psig	58
Maximum air inlet temperature	°C	46
Maximum air inlet temperature	°F	115
Minimum ambient temperature	°C	0
Minimum ambient temperature	°F	32

## 9.4 Compressor data



**Note:** The data is valid under the reference conditions. See section *Reference conditions and limitations*.

### GA 5 VSD<sup>s</sup>

Normal effective working pressure	bar(e)	4	7	10	13
Maximum effective working pressure, Pack	bar(e)	13	13	13	13
Maximum effective working pressure, Full-Feature	bar(e)	12.75	12.75	12.75	12.75
Maximum motor shaft speed	rpm	4500	4500	3680	2860
Minimum motor shaft speed	rpm	1600	1600	1600	1600
Nominal motor power	kW	5	5	5	5
Total amount of refrigerant, Full-Feature	kg	0.39	0.39	0.39	0.39
Oil capacity	l	6.5	6.5	6.5	6.5

Sound pressure level (according to ISO 2151(2004))	dB(A)	62	62	62	62
--	-------	----	----	----	----

**GA 7 VSD<sup>s</sup>**

Normal effective working pressure	bar(e)	4	7	10	13
Maximum effective working pressure, Pack	bar(e)	13	13	13	13
Maximum effective working pressure, Full-Feature	bar(e)	12.75	12.75	12.75	12.75
Maximum motor shaft speed	rpm	5400	5400	4600	3800
Minimum motor shaft speed	rpm	1900	1900	1900	1900
Nominal motor power	kW	7	7	7	7
Total amount of refrigerant, Full-Feature	kg	0.39	0.39	0.39	0.39
Oil capacity	l	7	7	7	7
Sound pressure level (according to ISO 2151(2004))	dB(A)	62	62	62	62

**GA 11 VSD<sup>s</sup>**

Normal effective working pressure	bar(e)	4	7	10
Maximum effective working pressure, Pack	bar(e)	10.5	10.5	10.5

Maximum effective working pressure, Full-Feature	bar(e)	10.25	10.25	10.25
Maximum motor shaft speed	rpm	4600	4600	3829
Minimum motor shaft speed	rpm	1000	1000	1000
Nominal motor power	kW	11	11	11
Total amount of refrigerant, Full-Feature	kg	0.44	0.44	0.44
Oil capacity	l	11	11	11
Sound pressure level (according to ISO 2151(2004))	dB(A)	67	67	67

**Table 19: Low pressure variant**

Normal effective working pressure	bar(e)	4	7	10	13
Maximum effective working pressure, Pack	bar(e)	13	13	13	13
Maximum effective working pressure, Full-Feature	bar(e)	12.75	12.75	12.75	12.75
Maximum motor shaft speed	rpm	8400	8400	7350	6300
Minimum motor shaft speed	rpm	1900	1900	1900	1900
Nominal motor power	kW	11	11	11	11
Total amount of refrigerant, Full-Feature	kg	0.44	0.44	0.44	0.44
Oil capacity	l	8.5	8.5	8.5	8.5

Sound pressure level (according to ISO 2151(2004))	dB(A)	67	67	67	67
--	-------	----	----	----	----

**Table 20: High pressure variant**

**GA 15 VSD<sup>s</sup>**

Normal effective working pressure	bar(e)	4	7	10
Maximum effective working pressure, Pack	bar(e)	10.5	10.5	10.5
Maximum effective working pressure, Full-Feature	bar(e)	10.25	10.25	10.25
Maximum motor shaft speed	rpm	5850	5850	4993
Minimum motor shaft speed	rpm	1000	1000	1000
Nominal motor power	kW	15	15	15
Total amount of refrigerant, Full-Feature	kg	0.75	0.75	0.75
Oil capacity	l	11	11	11
Sound pressure level (according to ISO 2151(2004))	dB(A)	69	69	69

**Table 21: Low pressure variant**

Normal effective working pressure	bar(e)	4	7	10	13
Maximum effective working pressure, Pack	bar(e)	13	13	13	13
Maximum effective working pressure, Full-Feature	bar(e)	12.75	12.75	12.75	12.75



Maximum motor shaft speed	rpm	9150	9150	8957	7800
Minimum motor shaft speed	rpm	1900	1900	1900	1900
Nominal motor power	kW	15	15	15	15
Total amount of refrigerant, Full-Feature	kg	0.75	0.75	0.75	0.75
Oil capacity	l	8.5	8.5	8.5	8.5
Sound pressure level (according to ISO 2151(2004))	dB(A)	69	69	69	69

**Table 22: High pressure variant**

**GA 18 VSD<sup>s</sup>**

Normal effective working pressure	bar(e)	4	7	10	13
Maximum effective working pressure, Pack	bar(e)	13	13	13	13
Maximum effective working pressure, Full-Feature	bar(e)	12.75	12.75	12.75	12.75
Maximum motor shaft speed	rpm	7600	7600	6650	5700
Minimum motor shaft speed	rpm	1000	1000	1000	1000
Nominal motor power	kW	18	18	18	18
Total amount of refrigerant, Full-Feature	kg	0.75	0.75	0.75	0.75
Oil capacity	l	12	12	12	12

Sound pressure level (according to ISO 2151(2004))	dB(A)	69	69	69	69
--	-------	----	----	----	----

## 9.5 Technical data controller

### General

Supply voltage	24 V AC /16 VA 50/60Hz (+40%/-30%) 24 V DC/0.7 A
Type of protection	IP54 (front) IP21 (back)
<ul style="list-style-type: none"> <li>• Operating temperature range</li> <li>• Storage temperature range</li> </ul>	<ul style="list-style-type: none"> <li>• -10°C.....+60°C (14 °F .....140 °F)</li> <li>• -30°C.....+70°C (-22 °F .....158 °F)</li> </ul>
Permissible humidity	Relative humidity 90% No condensation
Mounting	Cabinet door

## 9.6 Inputs and outputs

### Digital input

Strip	Description	PIN	Tag
X3	DI01	1	Remote start/stop
	24V	2	
	DI02	3	Remote pressure selection
	24V	4	
	DI03	5	Remote pressure sensing
	24V	6	
	DI04	7	Power duct fan alarm (option)
	24V	8	Empty
	DI05	9	Empty
	24V	10	Empty
	DI06	11	Empty
	24V	12	Empty
	DI07	13	Empty
	24V	14	Empty
	DI08	15	Empty
	24V	16	Empty
	DI09	17	Empty
	24V	18	Empty
	DI10	19	Empty
	24V	20	Empty

### Digital output

Strip	Description	PIN	Tag
X4	NO1	1	Potential free contacts
	COM	2	General Warning
	NO2	3	Potential free contacts
	COM	4	General Shutdown
	NO3	5	Potential free contacts Automatic Operation
	COM	6	
	NO4	7	K04 Not Used
	COM	8	
	NO5	9	K05 Not Used
	COM	10	

Digital out

Strip	Description	PIN	Tag
X7	DO01	1	Empty
	24V	2	General warning
	DO02	3	Empty
	24V	4	General shutdown
	DO03	5	Empty
	24V	6	Automatic operation
	DO04	7	Empty
	24V	8	Empty
	DO05	9	Empty
	24V	10	Empty
	DO06	11	Empty
	24V	12	Empty
	DO07	13	Dryer (GND)
	24V	14	Dryer (24V)
	DO08	15	Empty
	24V	16	Empty
	DO09	17	Y1 Blow-off Solenoid
	24V	18	Valve
	DO10	19	Y2 recirculation
	24V	20	Solenoid Valve (CPC)

Analog input PT1000

Strip	Description	PIN	Tag
X5	T01+	1	Empty
	T01-	2	
	T02+	3	TT90 - LAT dryer temperature
	T02-	4	
	T03+	5	TT11 - Element outlet temperature
	T03-	6	
	T04+	7	TT53 - Energy recovery inlet temperature (option)
	T04-	8	
	T05+	9	TT54 - Energy recovery outlet temperature (option)
	T05-	10	
	T06+	11	TT55 - Oil injection temperature (option*)
	T06-	12	
	T07+	13	TT56 - Oil cooler outlet temperature (option*)
	T07-	14	
	T08+	15	Empty
	T08-	16	

\*These options are not released as standard options. Additional programming needs to be done in controller database to activate these.

**Analog input pressure**

Strip	Description	PIN	Tag
X6	GND	1	PT20 - Outlet pressure
	P01	3	
	5V	5	
	GND	2	PT12 - Vessel pressure (option*)
	P02	4	
	5V	6	
	GND	7	Empty
	P03	9	MT01/TT01 - Humidity temperature sensor (ambient temperature)
	5V	11	Empty
	GND	8	MT01/TT01 - Humidity temperature sensor (relative humidity)
	P04	10	
	5V	12	

\*These options are not released as standard options. Additional programming needs to be done in controller database to activate these.

**Analog in/out**

Strip	Description	PIN	Tag
X9	GND	1	Empty
	AI01	2	Empty
	24V	3	Empty
	GND	4	Empty
	AI02	5	Empty
	24V	6	Empty
	GND	7	Power duct fan (option)
	AO03	8	Power duct fan (option)
	24V	9	Power duct fan (option)
	GND	10	Empty
	AO04	11	Empty
	24V	12	Empty

**Neos Next control board cabling**

Connector	Description	Wiring recommendations
J1/CN2	CAN	Refer to <i>CiA Draft recommendation proposal 303-1</i>
X1	Safe torque off (STO)	Wire size 1x1.5 mm <sup>2</sup> Input current: 9.8mA to 12mA
X2	Ethernet	Ethernet CAT5 cables
X3	24V digital input	Wire size 1x1.5 mm <sup>2</sup> Input current: 9.8mA to 12mA

Connector	Description	Wiring recommendations
X4	Digital output relay	Wire size 2.5mm <sup>2</sup> suitable for 250VAC, 8A
X5	Pt1000 temperature sensors	Wire size 1x1.5 mm <sup>2</sup> Shielded twisted pair
X6	Pressure sensor	Wire size 1x1.5 mm <sup>2</sup> Shielded twisted pair
X7	24V digital output	Wire size 1x1.5 mm <sup>2</sup> Output current: 2A max
X8	24VDC output	Wire size 1x1.5 mm <sup>2</sup> Output current: 1.67A max
X9	Analog inputs/outputs	Wire size 1x1.5 mm <sup>2</sup>

## 10 Instructions for use

### Air/oil separator vessel

This vessel can contain pressurised air; this can be potentially dangerous if the equipment is misused.

This vessel must only be used as a compressed air/oil separator and must be operated within the limits specified on the data plate.

No alterations must be made to this vessel by welding, drilling or any other mechanical methods without the written permission of the manufacturer.

The safety valve must correspond with pressure surges of 1.1 times the maximum allowable operating pressure. It should guarantee that the pressure will not permanently exceed the maximum allowable operating pressure of the vessel.

Use only oil as specified by the manufacturer.

This vessel has been designed and built to guarantee an operational lifetime in excess of 20 years.

The vessel needs a yearly visual inspection.

National legislation may require in service inspection.

## 11 Guidelines for inspection

On the Declaration of Conformity / Declaration by the Manufacturer, the harmonised and/or other standards that have been used for the design are shown and/or referred to.

The Declaration of Conformity / Declaration by the Manufacturer is part of the documentation that is supplied with this compressor.

Local legal requirements and/or use outside the limits and/or conditions as specified by the manufacturer may require other inspection periods as mentioned below.



## 12 Pressure equipment directives

### Components subject to 2014/68/EU Pressure Equipment Directive

The following table contains the necessary information for the inspection of all pressure equipment of category II and higher according to the Pressure Equipment Directive 2014/68/EU and all pressure equipment according to the Simple Pressure Vessel Directive 2014/29/EU.

Compressor type	Component	Description	Number of cycles (1)	Minimum wall thickness	Visual inspection frequency (2)	Hydrostatic inspection frequency (2)
GA 5 VSD <sup>s</sup> up to GA 18 VSD <sup>s</sup> , C55 variant	1625 4216 61	Oil separator vessel	2 x 10 <sup>6</sup>	3 mm	1 year	10 years
	2202 8891 05	Safety valve	-	-	-	-
GA 5 VSD <sup>s</sup> up to GA 18 VSD <sup>s</sup> , C67 variant	1649 8110 26	Oil separator vessel	2 x 10 <sup>6</sup>	3 mm	1 year	10 years
	0830 1009 98	Safety valve	-	-	-	-
GA 5 VSD <sup>s</sup> up to GA 11 VSD <sup>s</sup> , tank-mounted variant	1649 8110 50	Air tank	2 x 10 <sup>6</sup>	3 mm	1 year	10 years
	2202 8891 05	Safety valve - Air tank	-	-	-	-

Compressor type	Component	Description	Volume	Design pressure	Minimum and maximum design temperature	PED class
GA 5 VSD <sup>s</sup> up to GA 18 VSD <sup>s</sup> , C55 variant	1625 4216 61	Oil separator vessel	9 L	15 bar(e)	-10/120 °C	-
	2202 8891 05	Safety valve	-	14.5 bar(e)	-	IV
GA 5 VSD <sup>s</sup> up to GA 18 VSD <sup>s</sup> , C67 variant	1649 8110 26	Oil separator vessel	19 L	15 bar(e)	-10/120 °C	-
	0830 1009 98	Safety valve	-	14.5 bar(e)	-	IV
GA 5 VSD <sup>s</sup> up to GA 11 VSD <sup>s</sup> , tank-mounted variant	1649 8110 50	Air tank	200 L	15 bar(e)	-10/120 °C	-
	2202 8891 05	Safety valve - Air tank	-	14.5 bar(e)	-	IV

The compressors conform to PED smaller than category III.

(1) The number of cycles refers to the number of cycles from 0 bar(e) to maximum pressure.

(2) Other inspection techniques such as ultrasonic or X-ray are equivalent to hydrostatic testing for this equipment.

# 13 Declaration of conformity

Insert logo here

**EU DECLARATION OF CONFORMITY**

2 We, **(1)** declare under our sole responsibility, that the product  
 3 Machine name :  
 4 Machine type :  
 5 Serial number :

6 Which falls under the provisions of article 12.2 of the EC Directive 2006/42/EC on the approximation of the laws of the Member States relating to machinery, is in conformity with the relevant Essential Health and Safety Requirements of this directive.

The machinery complies also with the requirements of the following directives and their amendments as indicated.

	Directive on the approximation of laws of the Member States relating to	Harmonized and/or Technical Standards used	Att'mnt
7	<b>(2)</b>	<b>(3)</b>	
a			X
b			
c			X
d			
e			
f			
g			X

8a The harmonized and the technical standards used are identified in the attachments hereafter

8b <1> is authorized to compile the technical file.

	<b>Conformity of the specification to the directives</b>	<b>Conformity of the product to the specification and by implication to the directives</b>
11 Issued by	Engineering	Manufacturing
12 Name		
13 Signature		
14 Date		
15 Place		

84390D

**Figure 39: Typical example of a Declaration of Conformity document**

- (1) Contact address:  
Atlas Copco Airpower n.v.  
P.O. Box 100  
B-2610 Wilrijk (Antwerp)  
Belgium
- (2) Applicable directives
- (3) Standards used

On the Declaration of Conformity / Declaration by the Manufacturer, the harmonized and/or other standards that have been used for the design are shown and/or referred to.

The Declaration of Conformity / Declaration by the Manufacturer is part of the documentation that is supplied with this device.





